

# New Functions on the DD-500 (Ver. 1.10)

DD-500 Version 1.10 adds the following functions.

## Added Function for Phrase Loop (p. 9)

A method of clearing the phrase loop has been added.

With playback stopped, press the [TAP/CTL] switch twice. If you long-press the second time, the phrase is deleted without exiting Phrase Loop (the same as [B] switch + [TAP/CTL] switch).

You can use the [▼]/[▲] buttons to adjust the volume of the phrase (LOOP LEVEL).

## Added SYSTEM Parameters (p. 17)

The following system parameters have been added.

Parameter	Explanation	
TEMPO HOLD	Specifies whether the tempo (BPM) changes or is preserved when you switch patches. By preserving the tempo, you can also preserve the delay time. However, if the patch to which you switch has a different NOTE setting (such as ♩ or ♪), the delay time will also change.	<b>SYSTEM</b> BYPASS: BUFFERED PEDAL ACT: PUSH FSW HOLD TIME: 2sec FSW MODE: NORMAL TEMPO HOLD: ON
LOOP LEVEL	Specifies the volume of the recorded phrase.	<b>SYSTEM</b> FSW MODE: NORMAL TEMPO HOLD: ON USB MODE: GENERIC LOOP MODE: 96k MONO LOOP LEVEL: 100

