

# Patch list

## [1] PIANO

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
001	Pf01	JUNO-D Grand	PNO	64	1	—	—	2	SPLIT
002	Pf02	Soft Grand	PNO	64	2	—	—	2	SINGLE
003	Pf03	Bright Grand	PNO	64	3	—	—	2	SINGLE
004	Pf04	Dance Piano	PNO	64	4	—	—	2	SINGLE
005	Pf05	EL.Grand	PNO	64	5	—	—	2	SINGLE
006	Pf06	Honky-tonk 3	PNO	64	6	—	—	2	SINGLE
007	Pf07	LA Piano	PNO	64	7	—	—	4	SINGLE
008	Pf08	GrandPNO/ABs	PNO	64	8	—	—	2	SPLIT
009	Pf09	GrandPNO&Pad	PNO	64	9	—	—	4	DUAL
010	Pf10	GrandPNO&Vox	PNO	64	10	—	—	4	DUAL
011	Pf11	AEx PianoVox	PNO	64	11	—	—	6	DUAL
012	Pf12	Sweet Stage	EP	64	12	—	—	2	SINGLE
013	Pf13	JUNO-D EP	EP	64	13	—	—	2	SINGLE
014	Pf14	Chorus EP	EP	64	14	—	—	2	SINGLE
015	Pf15	70's Ballad	EP	64	15	—	—	2	SINGLE
016	Pf16	Dyno EP	EP	64	16	—	—	2	SINGLE
017	Pf17	Pure EP	EP	64	17	—	—	1	SINGLE
018	Pf18	EP Panner	EP	64	18	—	—	2	SINGLE
019	Pf19	Tremolo EP	EP	64	19	—	—	1	SINGLE
020	Pf20	Tremolo Dyno	EP	64	20	—	—	2	SINGLE
021	Pf21	MKS20 EP 1	EP	64	21	—	—	2	SINGLE
022	Pf22	MKS20 EP 2	EP	64	22	—	—	2	SINGLE
023	Pf23	Touch EP	EP	64	23	—	—	1	SINGLE
024	Pf24	Phase EP 1	EP	64	24	—	—	2	SINGLE
025	Pf25	Phase EP 2	EP	64	25	—	—	2	SINGLE
026	Pf26	Phase EP 3	EP	64	26	—	—	4	DUAL
027	Pf27	Psycho EP	EP	64	27	—	—	2	SINGLE
028	Pf28	Stage EP/Bs	EP	64	28	—	—	2	SPLIT
029	Pf29	Wurly EP	EP	64	29	—	—	1	SINGLE
030	Pf30	Sine EP	EP	64	30	—	—	2	SINGLE
031	Pf31	FM EP 1	EP	64	31	—	—	1	SINGLE
032	Pf32	St.FM EP	EP	64	32	—	—	2	SINGLE
033	Pf33	Stacked EP	EP	64	33	—	—	2	SINGLE
034	Pf34	FM EP 2	EP	64	34	—	—	2	SINGLE
035	Pf35	Hard FM	EP	64	35	—	—	2	SINGLE
036	Pf36	EP & Vox	EP	64	36	—	—	4	DUAL
037	Pf37	Piano 1	PNO	67	1	0	1	2	SPLIT
038	Pf38	Piano 1w	PNO	67	2	1	1	1	SPLIT
039	Pf39	European Pf	PNO	67	3	2	1	2	SINGLE
040	Pf40	Piano 2	PNO	67	4	0	2	2	SINGLE
041	Pf41	Piano 2w	PNO	67	5	1	2	1	SINGLE
042	Pf42	Piano 3	PNO	67	6	0	3	2	SINGLE
043	Pf43	Piano 3w	PNO	67	7	1	3	1	SINGLE
044	Pf44	Honky-tonk	PNO	67	8	0	4	2	SINGLE
045	Pf45	Honky-tonk 2	PNO	67	9	1	4	2	SINGLE
046	Pf46	E.Piano 1	EP	67	10	0	5	1	SINGLE
047	Pf47	St.Soft EP	EP	67	11	1	5	2	SINGLE
048	Pf48	FM+SA EP	EP	67	12	2	5	2	SINGLE
049	Pf49	60's EP	EP	67	13	3	5	1	SINGLE
050	Pf50	E.Piano 2	EP	67	14	0	6	1	SINGLE
051	Pf51	Detuned EP 2	EP	67	15	1	6	2	SINGLE
052	Pf52	St.FM EP	EP	67	16	2	6	2	SINGLE
053	Pf53	EP Legend	EP	67	17	3	6	2	SINGLE
054	Pf54	EP Phase	EP	67	18	4	6	2	SINGLE

## [2] KBD & ORG

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
055	Ky01	JUNO-D Fanta	BEL	64	37	—	—	5	DUAL
056	Ky02	JUNO-D Bell	BEL	64	38	—	—	4	SINGLE
057	Ky03	Singing Bell	BEL	64	39	—	—	2	SINGLE
058	Ky04	Pretty Bell	BEL	64	40	—	—	2	SINGLE
059	Ky05	Hyper Bell	BEL	64	41	—	—	2	SINGLE
060	Ky06	Warm Bell	BEL	64	42	—	—	2	SINGLE
061	Ky07	SouthernWind	BEL	64	43	—	—	4	SINGLE
062	Ky08	MOD Bell	BEL	64	44	—	—	6	DUAL
063	Ky09	MOD 5th Bell	BEL	64	45	—	—	4	DUAL
064	Ky10	Mysterious	BEL	64	46	—	—	4	SINGLE

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
065	Ky11	JU-2 Bell	BEL	64	47	—	—	2	SINGLE
066	Ky12	AEx SynBells	BEL	64	48	—	—	8	DUAL
067	Ky13	Clav 1	KEY	64	49	—	—	1	SINGLE
068	Ky14	Clav 2	KEY	64	50	—	—	2	SINGLE
069	Ky15	Clav 3	KEY	64	51	—	—	1	SINGLE
070	Ky16	Clav 4	KEY	64	52	—	—	1	SINGLE
071	Ky17	Phaser Clav	KEY	64	53	—	—	1	SINGLE
072	Ky18	JU-2 Clav 1	KEY	64	54	—	—	1	SINGLE
073	Ky19	JU-2 Clav 2	KEY	64	55	—	—	2	SINGLE
074	Ky20	Harpichord2	KEY	64	56	—	—	2	SINGLE
075	Ky21	JUNO-D Marimba	MLT	64	57	—	—	1	SINGLE
076	Ky22	JUNO-D Vibe	MLT	64	58	—	—	2	SINGLE
077	Ky23	SA Vibe	MLT	64	59	—	—	1	SINGLE
078	Ky24	JUNO-D Org 1	ORG	64	60	—	—	3	SINGLE
079	Ky25	JUNO-D Org 2	ORG	64	61	—	—	3	SINGLE
080	Ky26	JUNO-D Org 3	ORG	64	62	—	—	1	SINGLE
081	Ky27	JUNO-D Org 4	ORG	64	63	—	—	1	SINGLE
082	Ky28	JUNO-D Org 5	ORG	64	64	—	—	3	SINGLE
083	Ky29	Jazz Organ 1	ORG	64	65	—	—	1	SINGLE
084	Ky30	Jazz Organ 2	ORG	64	66	—	—	1	SINGLE
085	Ky31	R&B Organ	ORG	64	67	—	—	3	SINGLE
086	Ky32	Power B Slw	ORG	64	68	—	—	1	SINGLE
087	Ky33	Power B Fst	ORG	64	69	—	—	1	SINGLE
088	Ky34	Gospel B	ORG	64	70	—	—	3	SINGLE
089	Ky35	Dist Mad Org	ORG	64	71	—	—	2	SINGLE
090	Ky36	Purple B	ORG	64	72	—	—	2	SINGLE
091	Ky37	Animal Organ	ORG	64	73	—	—	1	SINGLE
092	Ky38	Surf Organ	ORG	64	74	—	—	1	SINGLE
093	Ky39	Old Organ	ORG	64	75	—	—	1	SINGLE
094	Ky40	D-50 Organ	ORG	64	76	—	—	1	SINGLE
095	Ky41	House Organ	ORG	64	77	—	—	1	SINGLE
096	Ky42	Garage Organ	ORG	64	78	—	—	2	SINGLE
097	Ky43	Club Organ	ORG	64	79	—	—	2	SINGLE
098	Ky44	FM Prc Organ	ORG	64	80	—	—	1	SINGLE
099	Ky45	PipeOrgan/Bs	ORG	64	81	—	—	1	SPLIT
100	Ky46	Vodkakordion	ACD	64	82	—	—	4	SINGLE
101	Ky47	Squeeze Me!	ACD	64	83	—	—	4	SINGLE
102	Ky48	Guinguette	ACD	64	84	—	—	4	SINGLE
103	Ky49	Harpichord	KEY	67	19	0	7	1	SINGLE
104	Ky50	Coupled Hps.	KEY	67	20	1	7	2	SINGLE
105	Ky51	Harp.si.w	KEY	67	21	2	7	1	SINGLE
106	Ky52	Harp.si.o	KEY	67	22	3	7	2	SINGLE
107	Ky53	Clav.	KEY	67	23	0	8	1	SINGLE
108	Ky54	Pulse Clav	KEY	67	24	1	8	1	SINGLE
109	Ky55	Celesta	KEY	67	25	0	9	1	SINGLE
110	Ky56	Glockenspiel	BEL	67	26	0	10	1	SINGLE
111	Ky57	Music Box	BEL	67	27	0	11	1	SINGLE
112	Ky58	Vibraphone	MLT	67	28	0	12	1	SINGLE
113	Ky59	Vibraphone w	MLT	67	29	1	12	1	SINGLE
114	Ky60	Marimba	MLT	67	30	0	13	1	SINGLE
115	Ky61	Marimba w	MLT	67	31	1	13	1	SINGLE
116	Ky62	Xylophone	MLT	67	32	0	14	1	SINGLE
117	Ky63	Tubular-bell	BEL	67	33	0	15	1	SINGLE
118	Ky64	Church Bell	BEL	67	34	1	15	1	SINGLE
119	Ky65	Carillon	BEL	67	35	2	15	1	SINGLE
120	Ky66	Organ 1	ORG	67	37	0	17	3	SINGLE
121	Ky67	Trem. Organ	ORG	67	38	1	17	2	SINGLE
122	Ky68	60's Organ 1	ORG	67	39	2	17	2	SINGLE
123	Ky69	70's E.Organ	ORG	67	40	3	17	2	SINGLE
124	Ky70	Organ 2	ORG	67	41	0	18	1	SINGLE
125	Ky71	Chorus Or.2	ORG	67	42	1	18	3	SINGLE
126	Ky72	Perc. Organ	ORG	67	43	2	18	2	SINGLE
127	Ky73	Organ 3	ORG	67	44	0	19	2	SINGLE
128	Ky74	Church Org.1	ORG	67	45	0	20	1	SINGLE
129	Ky75	Church Org.2	ORG	67	46	1	20	2	SINGLE
130	Ky76	Church Org.3	ORG	67	47	2	20	2	SINGLE
131	Ky77	Reed Organ	ORG	67	48	0	21	1	SINGLE
132	Ky78	Puff Organ	ORG	67	49	1	21	2	SINGLE
133	Ky79	Accordion Fr	ACD	67	50	0	22	2	SINGLE
134	Ky80	Accordion It	ACD	67	51	1	22	2	SINGLE
135	Ky81	Harmonica	HRM	67	52	0	23	1	SINGLE
136	Ky82	Bandoneon	ACD	67	53	0	24	2	SINGLE
137	Ky83	Crystal	BEL	68	56	0	99	2	SINGLE

## Patch list

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
138	Ky84	Syn Mallet	BEL	68	57	1	99	1	SINGLE
139	Ky85	Tinkle Bell	BEL	68	75	0	113	3	SINGLE
140	Ky86	Steel Drums	MLT	68	77	0	115	1	SINGLE

### [3] GUITAR

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
141	Gt01	JUNO-D Gtr	AGT	64	85	—	—	4	DUAL
142	Gt02	JUNO-D AcGtr	AGT	64	86	—	—	2	SINGLE
143	Gt03	JUNO-D AGtr2	AGT	64	87	—	—	1	SINGLE
144	Gt04	12str Gtr 2	AGT	64	88	—	—	2	SINGLE
145	Gt05	Nylon Guitar	AGT	64	89	—	—	2	SINGLE
146	Gt06	Spanish Gtr	AGT	64	90	—	—	2	SINGLE
147	Gt07	Requint Gtr	AGT	64	91	—	—	2	SINGLE
148	Gt08	AEx BeyondGt	AGT	64	92	—	—	6	DUAL
149	Gt09	JUNO-D EG 1	EGT	64	93	—	—	1	SINGLE
150	Gt10	JUNO-D EG 2	EGT	64	94	—	—	1	SINGLE
151	Gt11	St.Strat Gtr	EGT	64	95	—	—	2	SINGLE
152	Gt12	12str E-Gtr	EGT	64	96	—	—	2	SINGLE
153	Gt13	JUNO-D JazzG	EGT	64	97	—	—	1	SINGLE
154	Gt14	E.Guitar	EGT	64	98	—	—	1	SINGLE
155	Gt15	Funk Gtr	EGT	64	99	—	—	1	SINGLE
156	Gt16	Wah Guitar	EGT	64	100	—	—	1	SINGLE
157	Gt17	Wah-Wah Gtr	EGT	64	101	—	—	1	SINGLE
158	Gt18	Darmstrat	DGT	64	102	—	—	4	DUAL
159	Gt19	Dazed Guitar	DGT	64	103	—	—	2	SINGLE
160	Gt20	OD-Gtr	DGT	64	104	—	—	2	SINGLE
161	Gt21	Heavy Gtr	DGT	64	105	—	—	1	SINGLE
162	Gt22	Dist Mute	DGT	64	106	—	—	1	SINGLE
163	Gt23	D.Mute Gtr	DGT	64	107	—	—	1	SINGLE
164	Gt24	5th OverDrv.	DGT	64	108	—	—	2	SINGLE
165	Gt25	Power Chord	DGT	64	109	—	—	2	SINGLE
166	Gt26	Nylon-str.Gt	AGT	67	54	0	25	2	SINGLE
167	Gt27	Ukulele	AGT	67	55	1	25	1	SINGLE
168	Gt28	Nylon Gt.o	AGT	67	56	2	25	2	SINGLE
169	Gt29	Nylon Gt.2	AGT	67	57	3	25	1	SINGLE
170	Gt30	Steel-str.Gt	AGT	67	58	0	26	1	SINGLE
171	Gt31	12-str.Gt	AGT	67	59	1	26	2	SINGLE
172	Gt32	Mandolin	AGT	67	60	2	26	2	SINGLE
173	Gt33	Steel + Body	AGT	67	61	3	26	2	SINGLE
174	Gt34	Jazz Gt.	EGT	67	62	0	27	1	SINGLE
175	Gt35	Pedal Steel	EGT	67	63	1	27	1	SINGLE
176	Gt36	Clean Gt.	EGT	67	64	0	28	1	SINGLE
177	Gt37	Chorus Gt.	EGT	67	65	1	28	2	SINGLE
178	Gt38	Mid Tone GTR	EGT	67	66	2	28	1	SINGLE
179	Gt39	Muted Gt.	EGT	67	67	0	29	1	SINGLE
180	Gt40	Funk Pop	EGT	67	68	1	29	1	SINGLE
181	Gt41	Funk Gt.2	EGT	67	69	2	29	1	SINGLE
182	Gt42	Jazz Man	EGT	67	70	3	29	2	SINGLE
183	Gt43	Overdrive Gt	DGT	67	71	0	30	2	SINGLE
184	Gt44	Guitar Pinch	DGT	67	72	1	30	1	SINGLE
185	Gt45	DistortionGt	DGT	67	73	0	31	2	SINGLE
186	Gt46	Feedback Gt.	DGT	67	74	1	31	2	SINGLE
187	Gt47	Dist Rtm GTR	DGT	67	75	2	31	1	SINGLE
188	Gt48	Gt.Harmonics	EGT	67	76	0	32	1	SINGLE
189	Gt49	Gt. Feedback	EGT	67	77	1	32	1	SINGLE
190	Gt50	Atmosphere	AGT	68	58	0	100	2	SINGLE
191	Gt51	Gt.FretNoise	AGT	68	88	0	121	1	SINGLE
192	Gt52	Gt.Cut Noise	AGT	68	89	1	121	1	SINGLE
193	Gt53	String Slap	AGT	68	90	2	121	1	SINGLE

### [4] ORCH

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
194	Oc01	JUNO-D Str 1	STR	64	110	—	—	4	SINGLE
195	Oc02	JUNO-D Str 2	STR	64	111	—	—	4	DUAL
196	Oc03	JUNO-D Str 3	STR	64	112	—	—	4	DUAL
197	Oc04	PortaStrings	STR	64	113	—	—	4	SINGLE

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
198	Oc05	StringsSect1	STR	64	114	—	—	4	DUAL
199	Oc06	StringsSect2	STR	64	115	—	—	4	DUAL
200	Oc07	StringsSect3	STR	64	116	—	—	4	DUAL
201	Oc08	StringsSect4	STR	64	117	—	—	3	DUAL
202	Oc09	VeloStrings	STR	64	118	—	—	5	DUAL
203	Oc10	SlowStrings1	STR	64	119	—	—	2	SINGLE
204	Oc11	SlowStrings2	STR	64	120	—	—	2	SINGLE
205	Oc12	Oct Strings	STR	64	121	—	—	2	SINGLE
206	Oc13	Str Spic 1	STR	64	122	—	—	1	SINGLE
207	Oc14	Str Spic 2	STR	64	123	—	—	2	DUAL
208	Oc15	Tron Strings	STR	64	124	—	—	1	SINGLE
209	Oc16	Tekno Str	STR	64	125	—	—	4	DUAL
210	Oc17	Dance Str	STR	64	126	—	—	1	SINGLE
211	Oc18	JUNO-D Orch1	STR	64	127	—	—	4	DUAL
212	Oc19	JUNO-D Orch2	STR	64	128	—	—	5	DUAL
213	Oc20	JUNO-D Orch3	STR	65	1	—	—	3	SINGLE
214	Oc21	JUNO-D Orch4	STR	65	2	—	—	4	DUAL
215	Oc22	HybrdStrings	STR	65	3	—	—	5	DUAL
216	Oc23	JP Strings 1	STR	65	4	—	—	5	DUAL
217	Oc24	JP Strings 2	STR	65	5	—	—	3	DUAL
218	Oc25	JP Strings 3	STR	65	6	—	—	3	SINGLE
219	Oc26	JUNO-60 Str	STR	65	7	—	—	6	DUAL
220	Oc27	106 Strings	STR	65	8	—	—	3	DUAL
221	Oc28	JU-2 Str 1	STR	65	9	—	—	4	DUAL
222	Oc29	JU-2 Str 2	STR	65	10	—	—	5	DUAL
223	Oc30	OB Strings 1	STR	65	11	—	—	2	SINGLE
224	Oc31	OB Strings 2	STR	65	12	—	—	5	DUAL
225	Oc32	SawStrings 1	STR	65	13	—	—	2	SINGLE
226	Oc33	SawStrings 2	STR	65	14	—	—	6	DUAL
227	Oc34	AEx Orchestra	STR	65	15	—	—	6	DUAL
228	Oc35	JUNO-D Vln 1	STR	65	16	—	—	2	DUAL
229	Oc36	JUNO-D Vln 2	STR	65	17	—	—	2	SINGLE
230	Oc37	Violin Marc	STR	65	18	—	—	1	SINGLE
231	Oc38	JUNO-D Viola	STR	65	19	—	—	1	SINGLE
232	Oc39	JUNO-D Vc 1	STR	65	20	—	—	3	DUAL
233	Oc40	JUNO-D Vc 2	STR	65	21	—	—	2	SINGLE
234	Oc41	Cello Spic	STR	65	22	—	—	1	SINGLE
235	Oc42	JUNO-D CB	STR	65	23	—	—	1	SINGLE
236	Oc43	JUNO-D Pizz1	STR	65	24	—	—	5	DUAL
237	Oc44	JUNO-D Pizz2	STR	65	25	—	—	5	DUAL
238	Oc45	Trad Pizz	STR	65	26	—	—	1	SINGLE
239	Oc46	JUNO-D Harp	OCH	65	27	—	—	2	SINGLE
240	Oc47	JUNO-D Oboe	WND	65	28	—	—	1	SINGLE
241	Oc48	JUNO-D E.Hrn	WND	65	29	—	—	1	SINGLE
242	Oc49	JUNO-D Clar	WND	65	30	—	—	1	SINGLE
243	Oc50	JUNO-D Flt 1	FLT	65	31	—	—	1	SINGLE
244	Oc51	JUNO-D Flt 2	FLT	65	32	—	—	2	SINGLE
245	Oc52	Tron Flute	FLT	65	33	—	—	1	SINGLE
246	Oc53	Calliope-D	FLT	65	34	—	—	3	SINGLE
247	Oc54	JUNO-D Sicu	FLT	65	35	—	—	1	SINGLE
248	Oc55	JUNO-D Blow	FLT	65	36	—	—	3	SINGLE
249	Oc56	Club Hit	HIT	65	37	—	—	4	SINGLE
250	Oc57	Back Hit	HIT	65	38	—	—	1	SINGLE
251	Oc58	Techno Hit	HIT	65	39	—	—	1	SINGLE
252	Oc59	Philly Hit	HIT	65	40	—	—	1	SINGLE
253	Oc60	Violin	STR	67	94	0	41	2	SINGLE
254	Oc61	Slow Violin	STR	67	95	1	41	1	SINGLE
255	Oc62	Viola	STR	67	96	0	42	1	SINGLE
256	Oc63	Cello	STR	67	97	0	43	2	SINGLE
257	Oc64	Contrabass	STR	67	98	0	44	1	SINGLE
258	Oc65	Tremolo Str	STR	67	99	0	45	2	SINGLE
259	Oc66	PizzicatoStr	STR	67	100	0	46	1	SINGLE
260	Oc67	Strings	STR	67	104	0	49	2	SINGLE
261	Oc68	Orchestra	OCH	67	105	1	49	3	SINGLE
262	Oc69	60s Strings	STR	67	106	2	49	2	SINGLE
263	Oc70	Slow Strings	STR	67	107	0	50	2	SINGLE
264	Oc71	Syn.Strings1	STR	67	108	0	51	2	SINGLE
265	Oc72	Syn.Strings3	STR	67	109	1	51	2	SINGLE
266	Oc73	OrchestraHit	HIT	67	117	0	56	2	SINGLE
267	Oc74	Bass Hit	HIT	67	118	1	56	2	SINGLE
268	Oc75	6th Hit	HIT	67	119	2	56	2	SINGLE
269	Oc76	Euro Hit	HIT	67	120	3	56	2	SINGLE
270	Oc77	Oboe	WND	68	16	0	69	1	SINGLE

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
271	Oc78	English Horn	WND	68	17	0	70	1	SINGLE
272	Oc79	Bassoon	WND	68	18	0	71	1	SINGLE
273	Oc80	Clarinet	WND	68	19	0	72	1	SINGLE
274	Oc81	Piccolo	FLT	68	20	0	73	1	SINGLE
275	Oc82	Flute	FLT	68	21	0	74	1	SINGLE
276	Oc83	Recorder	FLT	68	22	0	75	1	SINGLE
277	Oc84	Pan Flute	FLT	68	23	0	76	1	SINGLE
278	Oc85	Bottle Blow	FLT	68	24	0	77	2	SINGLE
279	Oc86	Whistle	FLT	68	26	0	79	2	SINGLE
280	Oc87	Ocarina	FLT	68	27	0	80	2	SINGLE
281	Oc88	Fiddle	STR	68	73	0	111	1	SINGLE

**[5] WORLD**

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
282	Wr01	JUNO-D Sitar	PLK	65	41	—	—	1	SINGLE
283	Wr02	JUNO-D Shami	ETH	65	42	—	—	2	SINGLE
284	Wr03	JUNO-D Klmba	ETH	65	43	—	—	1	SINGLE
285	Wr04	Jublag	ETH	65	44	—	—	1	SINGLE
286	Wr05	Tin Whistle	ETH	65	45	—	—	1	SINGLE
287	Wr06	JUNO-D Shaku	ETH	65	46	—	—	1	SINGLE
288	Wr07	ShakuBamboo	ETH	65	47	—	—	4	SINGLE
289	Wr08	Nay	ETH	65	48	—	—	2	SINGLE
290	Wr09	AEx CelticFl	ETH	65	49	—	—	2	DUAL
291	Wr10	Santur	PLK	67	36	0	16	1	SINGLE
292	Wr11	Harp	PLK	67	101	0	47	1	SINGLE
293	Wr12	Yang Qin	PLK	67	102	1	47	2	SINGLE
294	Wr13	Shakuhachi	ETH	68	25	0	78	1	SINGLE
295	Wr14	Sitar	PLK	68	65	0	105	1	SINGLE
296	Wr15	Sitar 2	PLK	68	66	1	105	2	SINGLE
297	Wr16	Banjo	FRT	68	67	0	106	1	SINGLE
298	Wr17	Shamisen	PLK	68	68	0	107	1	SINGLE
299	Wr18	Koto	PLK	68	69	0	108	2	SINGLE
300	Wr19	Taisho Koto	PLK	68	70	1	108	2	SINGLE
301	Wr20	Kalimba	PLK	68	71	0	109	1	SINGLE
302	Wr21	Bagpipe	ETH	68	72	0	110	2	SINGLE
303	Wr22	Shanai	ETH	68	74	0	112	1	SINGLE

**[6] BRASS**

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
304	Br01	JUNO-D Brass	BRS	65	50	—	—	8	DUAL
305	Br02	Brass Sect 1	BRS	65	51	—	—	2	SINGLE
306	Br03	Brass Sect 2	BRS	65	52	—	—	4	SINGLE
307	Br04	Brass Sect 3	BRS	65	53	—	—	2	SINGLE
308	Br05	Brass Sect 4	BRS	65	54	—	—	2	SINGLE
309	Br06	Tp&Tb Sect 1	BRS	65	55	—	—	2	SINGLE
310	Br07	Tp&Tb Sect 2	BRS	65	56	—	—	2	SINGLE
311	Br08	Tp Sect	BRS	65	57	—	—	1	SINGLE
312	Br09	Tb Sect	BRS	65	58	—	—	1	SINGLE
313	Br10	Brass sfz	BRS	65	59	—	—	2	SINGLE
314	Br11	St.Sax Sect	BRS	65	60	—	—	2	SINGLE
315	Br12	AEx UniTp+Tb	BRS	65	61	—	—	2	DUAL
316	Br13	F.HornSect 1	BRS	65	62	—	—	1	SINGLE
317	Br14	F.HornSect 2	BRS	65	63	—	—	2	DUAL
318	Br15	Wide FrHorns	BRS	65	64	—	—	2	SINGLE
319	Br16	Str + Horns	BRS	65	65	—	—	2	SINGLE
320	Br17	Orch Brass 1	BRS	65	66	—	—	2	SINGLE
321	Br18	Orch Brass 2	BRS	65	67	—	—	2	SINGLE
322	Br19	St.OrchBrs 1	BRS	65	68	—	—	2	SINGLE
323	Br20	St.OrchBrs 2	BRS	65	69	—	—	4	SINGLE
324	Br21	St.OrchBrs 3	BRS	65	70	—	—	4	SINGLE
325	Br22	Henry IV	BRS	65	71	—	—	4	SINGLE
326	Br23	Oct Brass	BRS	65	72	—	—	2	SINGLE
327	Br24	Power Saws	SBR	65	73	—	—	3	DUAL
328	Br25	106 Brass 1	SBR	65	74	—	—	6	DUAL
329	Br26	106 Brass 2	SBR	65	75	—	—	6	DUAL
330	Br27	LA Brass	SBR	65	76	—	—	4	SINGLE

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
331	Br28	Oct Syn Brs	SBR	65	77	—	—	6	DUAL
332	Br29	Soft SynBrs	SBR	65	78	—	—	4	DUAL
333	Br30	Deep SynBrs	SBR	65	79	—	—	4	DUAL
334	Br31	VeloBrass	SBR	65	80	—	—	2	SINGLE
335	Br32	JP Saw Brs	SBR	65	81	—	—	4	DUAL
336	Br33	OB Brass	SBR	65	82	—	—	5	DUAL
337	Br34	BPF Brass	SBR	65	83	—	—	4	DUAL
338	Br35	Dist SqrBrs	SBR	65	84	—	—	2	SINGLE
339	Br36	Soaring Horn	SBR	65	85	—	—	4	SINGLE
340	Br37	JUNO-D Tp 1	BRS	65	86	—	—	1	SINGLE
341	Br38	JUNO-D Tp 2	BRS	65	87	—	—	1	SINGLE
342	Br39	Bright Tp	BRS	65	88	—	—	2	SINGLE
343	Br40	Flugel Horn	BRS	65	89	—	—	1	SINGLE
344	Br41	Dual Tp	BRS	65	90	—	—	2	SINGLE
345	Br42	MuteTrumpet 1	BRS	65	91	—	—	1	SINGLE
346	Br43	MuteTrumpet 2	BRS	65	92	—	—	1	SINGLE
347	Br44	JUNO-D Tb 1	BRS	65	93	—	—	1	SINGLE
348	Br45	JUNO-D Tb 2	BRS	65	94	—	—	1	SINGLE
349	Br46	JUNO-D Tuba	BRS	65	95	—	—	1	SINGLE
350	Br47	JUNO-D F.Hrn	BRS	65	96	—	—	1	SINGLE
351	Br48	JUNO-D S.Sax	SAX	65	97	—	—	1	SINGLE
352	Br49	JUNO-D A.Sax	SAX	65	98	—	—	1	SINGLE
353	Br50	AltoSax Sft	SAX	65	99	—	—	1	SINGLE
354	Br51	Honky Tenor	SAX	65	100	—	—	1	SINGLE
355	Br52	JUNO-D T.Sax	SAX	65	101	—	—	2	SINGLE
356	Br53	Blown Tenor	SAX	65	102	—	—	1	SINGLE
357	Br54	JUNO-D B.Sax	SAX	65	103	—	—	1	SINGLE
358	Br55	Trumpet	BRS	67	121	0	57	2	SINGLE
359	Br56	Dark Trumpet	BRS	67	122	1	57	1	SINGLE
360	Br57	Trombone	BRS	67	123	0	58	1	SINGLE
361	Br58	Trombone 2	BRS	67	124	1	58	1	SINGLE
362	Br59	Bright Tb	BRS	67	125	2	58	1	SINGLE
363	Br60	Tuba	BRS	67	126	0	59	1	SINGLE
364	Br61	MutedTrumpet	BRS	67	127	0	60	1	SINGLE
365	Br62	MuteTrumpet2	BRS	67	128	1	60	1	SINGLE
366	Br63	French Horns	BRS	68	1	0	61	1	SINGLE
367	Br64	Fr.Horn 2	BRS	68	2	1	61	2	SINGLE
368	Br65	Brass 1	BRS	68	3	0	62	2	SINGLE
369	Br66	Brass 2	BRS	68	4	1	62	2	SINGLE
370	Br67	Synth Brass1	SBR	68	5	0	63	2	SINGLE
371	Br68	JP Brass	SBR	68	6	1	63	2	SINGLE
372	Br69	Oct SynBrass	SBR	68	7	2	63	2	SINGLE
373	Br70	Jump Brass	SBR	68	8	3	63	1	SINGLE
374	Br71	Synth Brass2	SBR	68	9	0	64	2	SINGLE
375	Br72	SynBrass sfz	SBR	68	10	1	64	2	SINGLE
376	Br73	Velo Brass 1	SBR	68	11	2	64	2	SINGLE
377	Br74	Soprano Sax	SAX	68	12	0	65	1	SINGLE
378	Br75	Alto Sax	SAX	68	13	0	66	1	SINGLE
379	Br76	Tenor Sax	SAX	68	14	0	67	1	SINGLE
380	Br77	Baritone Sax	SAX	68	15	0	68	1	SINGLE

**[7] VOCAL & PAD**

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
381	Vo01	Jazz Scat	VOX	65	104	—	—	1	SINGLE
382	Vo02	JUNO-D Choir	VOX	65	105	—	—	2	SINGLE
383	Vo03	JUNO-D Vox	VOX	65	106	—	—	2	SINGLE
384	Vo04	FemMm Choir	VOX	65	107	—	—	1	SINGLE
385	Vo05	St.ChoirAhs	VOX	65	108	—	—	4	SINGLE
386	Vo06	SH-2000 Vox	VOX	65	109	—	—	1	SINGLE
387	Vo07	FM Vox	VOX	65	110	—	—	1	SINGLE
388	Vo08	Vox Pad	VOX	65	111	—	—	2	SINGLE
389	Vo09	ChaosChoir 1	VOX	65	112	—	—	8	DUAL
390	Vo10	ChaosChoir 2	VOX	65	113	—	—	7	DUAL
391	Vo11	AEx StackVox	VOX	65	114	—	—	4	DUAL
392	Vo12	JUNO-D Cosmo	SPD	65	115	—	—	4	DUAL
393	Vo13	JUNO-D Space	SPD	65	116	—	—	5	DUAL
394	Vo14	Heaven Pad	SPD	65	117	—	—	2	SINGLE
395	Vo15	D-50 Retour	SPD	65	118	—	—	4	SINGLE
396	Vo16	Warm Sqr Pad	SPD	65	119	—	—	3	SINGLE

# Patch list

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
397	Vo17	Hollow Pad 1	SPD	65	120	—	—	8	DUAL
398	Vo18	JP8 Hollow	SPD	65	121	—	—	4	SINGLE
399	Vo19	JP8Haunting	SPD	65	122	—	—	4	SINGLE
400	Vo20	OB2 Pad 1	SPD	65	123	—	—	2	SINGLE
401	Vo21	OB2 Pad 2	SPD	65	124	—	—	1	SINGLE
402	Vo22	Saw Sweep 1	SPD	65	125	—	—	3	SINGLE
403	Vo23	Saw Sweep 2	SPD	65	126	—	—	2	SINGLE
404	Vo24	Saw Sweep 3	SPD	65	127	—	—	3	SINGLE
405	Vo25	Soft Pad 1	SPD	65	128	—	—	3	DUAL
406	Vo26	Soft Pad 2	SPD	66	1	—	—	1	SINGLE
407	Vo27	Oct SynStr	SPD	66	2	—	—	6	DUAL
408	Vo28	Stacked Pad	SPD	66	3	—	—	6	DUAL
409	Vo29	JUNO-D Pad	BPD	66	4	—	—	4	SINGLE
410	Vo30	SuperJupiter	BPD	66	5	—	—	4	SINGLE
411	Vo31	ReverseSweep	BPD	66	6	—	—	2	SINGLE
412	Vo32	JUNO-D Atmos	BPD	66	7	—	—	5	DUAL
413	Vo33	JUNO-D Comb	BPD	66	8	—	—	4	SINGLE
414	Vo34	Comb Pad	BPD	66	9	—	—	4	SINGLE
415	Vo35	Saws Strobe	BPD	66	10	—	—	8	DUAL
416	Vo36	Star Dust	BPD	66	11	—	—	4	SINGLE
417	Vo37	Wind Pad	BPD	66	12	—	—	7	DUAL
418	Vo38	Shakupad	BPD	66	13	—	—	3	SINGLE
419	Vo39	Sweep Stack	BPD	66	14	—	—	4	SINGLE
420	Vo40	Reso Pad	BPD	66	15	—	—	2	SINGLE
421	Vo41	ForwardSweep	BPD	66	16	—	—	2	SINGLE
422	Vo42	AEx StackPad	BPD	66	17	—	—	6	DUAL
423	Vo43	Syn.Strings2	SPD	67	110	0	52	2	SINGLE
424	Vo44	Choir Aahs	VOX	67	111	0	53	2	SINGLE
425	Vo45	Chorus Aahs	VOX	67	112	1	53	2	SINGLE
426	Vo46	Voice Oohs	VOX	67	113	0	54	1	SINGLE
427	Vo47	Humming	VOX	67	114	1	54	2	SINGLE
428	Vo48	SynVox	VOX	67	115	0	55	2	SINGLE
429	Vo49	Analog Voice	VOX	67	116	1	55	1	SINGLE
430	Vo50	Warm Pad	SPD	68	45	0	90	1	SINGLE
431	Vo51	Sine Pad	SPD	68	46	1	90	2	SINGLE
432	Vo52	Space Voice	VOX	68	48	0	92	2	SINGLE
433	Vo53	Itopia	VOX	68	49	1	92	2	SINGLE
434	Vo54	Bowed Glass	SPD	68	50	0	93	3	SINGLE
435	Vo55	Metal Pad	BPD	68	51	0	94	3	SINGLE
436	Vo56	Halo Pad	BPD	68	52	0	95	2	SINGLE
437	Vo57	Sweep Pad	SPD	68	53	0	96	1	SINGLE
438	Vo58	Soundtrack	SPD	68	55	0	98	2	SINGLE
439	Vo59	Echo Drops	BPD	68	61	0	103	1	SINGLE
440	Vo60	Echo Bell	BPD	68	62	1	103	2	SINGLE
441	Vo61	Echo Pan	BPD	68	63	2	103	2	SINGLE
442	Vo62	Star Theme	BPD	68	64	0	104	2	SINGLE

## [8] SYNTH

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
443	Sy01	JUNO-DTrance	SYN	66	18	—	—	6	DUAL
444	Sy02	Trance Keys	SYN	66	19	—	—	3	SINGLE
445	Sy03	Trance Pad	SYN	66	20	—	—	2	SINGLE
446	Sy04	DanceStack	SYN	66	21	—	—	5	DUAL
447	Sy05	JUNO-D Power	SYN	66	22	—	—	4	DUAL
448	Sy06	106 SawStack	SYN	66	23	—	—	2	DUAL
449	Sy07	JUNO-D Sweep	SYN	66	24	—	—	4	DUAL
450	Sy08	Pizz Saw	SYN	66	25	—	—	4	DUAL
451	Sy09	Sugar Key	SYN	66	26	—	—	2	SINGLE
452	Sy10	BriteSawKey	SYN	66	27	—	—	2	SINGLE
453	Sy11	Wire Keys	SYN	66	28	—	—	3	SINGLE
454	Sy12	DualWireKeys	SYN	66	29	—	—	5	DUAL
455	Sy13	JUNO-D Poly	SYN	66	30	—	—	4	DUAL
456	Sy14	JUNO-D Rave	TEK	66	31	—	—	5	DUAL
457	Sy15	Feedback 5th	TEK	66	32	—	—	6	DUAL
458	Sy16	Time Warp	TEK	66	33	—	—	3	SINGLE
459	Sy17	Riff the 5th	TEK	66	34	—	—	2	SINGLE
460	Sy18	Seq Pulse	TEK	66	35	—	—	2	SINGLE
461	Sy19	Chord Maj7	TEK	66	36	—	—	4	SINGLE
462	Sy20	JUNO-D Slice	PLS	66	37	—	—	3	DUAL

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
463	Sy21	Saw Impulse	PLS	66	38	—	—	3	SINGLE
464	Sy22	Slicer	PLS	66	39	—	—	5	DUAL
465	Sy23	Power Slice	PLS	66	40	—	—	3	DUAL
466	Sy24	Rndm Ending	PLS	66	41	—	—	2	SINGLE
467	Sy25	Rndm Pad	PLS	66	42	—	—	3	SINGLE
468	Sy26	Etherality	PLS	66	43	—	—	4	SINGLE
469	Sy27	LFO Pad	PLS	66	44	—	—	4	SINGLE
470	Sy28	Strobe-J	PLS	66	45	—	—	6	DUAL
471	Sy29	Step Pad	PLS	66	46	—	—	4	SINGLE
472	Sy30	RndmFltrChrd	PLS	66	47	—	—	4	SINGLE
473	Sy31	Just Before	FX	66	48	—	—	4	SINGLE
474	Sy32	JUNO-D Lead1	HLD	66	49	—	—	2	SINGLE
475	Sy33	JUNO-D Lead2	HLD	66	50	—	—	4	DUAL
476	Sy34	JUNO-D Lead3	HLD	66	51	—	—	2	SINGLE
477	Sy35	MG Lead 1	HLD	66	52	—	—	1	SINGLE
478	Sy36	MG Lead 2	HLD	66	53	—	—	1	SINGLE
479	Sy37	MG Lead 3	HLD	66	54	—	—	1	SINGLE
480	Sy38	MG Lead 4	HLD	66	55	—	—	1	SINGLE
481	Sy39	PM Saw	HLD	66	56	—	—	1	SINGLE
482	Sy40	Sqr&Saw Ld	HLD	66	57	—	—	4	SINGLE
483	Sy41	Horney Lead	HLD	66	58	—	—	1	SINGLE
484	Sy42	D-50 FatSaw	HLD	66	59	—	—	2	SINGLE
485	Sy43	P5 Saw	HLD	66	60	—	—	2	SINGLE
486	Sy44	MG Saw	HLD	66	61	—	—	1	SINGLE
487	Sy45	OB Saw	HLD	66	62	—	—	1	SINGLE
488	Sy46	Waspy Synth	HLD	66	63	—	—	2	SINGLE
489	Sy47	Naked Cheese	HLD	66	64	—	—	1	SINGLE
490	Sy48	Velo Cheese	HLD	66	65	—	—	3	SINGLE
491	Sy49	800 Lead	SLD	66	66	—	—	1	SINGLE
492	Sy50	OB Lead	SLD	66	67	—	—	2	SINGLE
493	Sy51	Shmoog	SLD	66	68	—	—	2	SINGLE
494	Sy52	JUNO-D SftLd	SLD	66	69	—	—	1	SINGLE
495	Sy53	Theramax	SLD	66	70	—	—	1	SINGLE
496	Sy54	JD Triangle	SLD	66	71	—	—	1	SINGLE
497	Sy55	Sine	SLD	66	72	—	—	1	SINGLE
498	Sy56	Twin Sine	SLD	66	73	—	—	2	SINGLE
499	Sy57	Square Wave	HLD	68	28	0	81	2	SINGLE
500	Sy58	MG Square	HLD	68	29	1	81	1	SINGLE
501	Sy59	2600 Sine	HLD	68	30	2	81	1	SINGLE
502	Sy60	Saw Wave	HLD	68	31	0	82	2	SINGLE
503	Sy61	OB2 Saw	HLD	68	32	1	82	1	SINGLE
504	Sy62	Doctor Solo	HLD	68	33	2	82	2	SINGLE
505	Sy63	Natural Lead	HLD	68	34	3	82	2	SINGLE
506	Sy64	SequencedSaw	HLD	68	35	4	82	2	SINGLE
507	Sy65	Syn.Calliope	SLD	68	36	0	83	2	SINGLE
508	Sy66	Chiffer Lead	SLD	68	37	0	84	2	SINGLE
509	Sy67	Charang	HLD	68	38	0	85	2	SINGLE
510	Sy68	Wire Lead	HLD	68	39	1	85	2	SINGLE
511	Sy69	Solo Vox	SLD	68	40	0	86	2	SINGLE
512	Sy70	5th Saw Wave	HLD	68	41	0	87	2	SINGLE
513	Sy71	Bass & Lead	HLD	68	42	0	88	2	SINGLE
514	Sy72	Delayed Lead	HLD	68	43	1	88	2	SINGLE
515	Sy73	Fantasia	SYN	68	44	0	89	2	SINGLE
516	Sy74	Polysynth	SYN	68	47	0	91	2	SINGLE
517	Sy75	Ice Rain	SYN	68	54	0	97	2	SINGLE
518	Sy76	Brightness	SYN	68	59	0	101	2	SINGLE
519	Sy77	Goblin	PLS	68	60	0	102	2	SINGLE
520	Sy78	Breath Noise	FX	68	91	0	122	1	SINGLE
521	Sy79	Fl.Key Click	FX	68	92	1	122	1	SINGLE

## [9] BASS

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
522	Bs01	TB Dist Saw	SBS	66	74	—	—	1	SINGLE
523	Bs02	Acid TB Bs	SBS	66	75	—	—	1	SINGLE
524	Bs03	FatTB Bass	SBS	66	76	—	—	2	SINGLE
525	Bs04	TB Bass	SBS	66	77	—	—	1	SINGLE
526	Bs05	MC202 Bass	SBS	66	78	—	—	1	SINGLE
527	Bs06	House Bass 1	SBS	66	79	—	—	1	SINGLE
528	Bs07	SH101 Bass 1	SBS	66	80	—	—	1	SINGLE
529	Bs08	SH101 Bass 2	SBS	66	81	—	—	1	SINGLE
530	Bs09	Dark Bass	SBS	66	82	—	—	2	SINGLE
531	Bs10	Smooth Bass	SBS	66	83	—	—	2	SINGLE
532	Bs11	Low Bass	SBS	66	84	—	—	2	SINGLE
533	Bs12	Deep Bass	SBS	66	85	—	—	3	SINGLE
534	Bs13	SH DullBass	SBS	66	86	—	—	2	SINGLE
535	Bs14	Square Bass	SBS	66	87	—	—	2	SINGLE
536	Bs15	Jungle Bass	SBS	66	88	—	—	1	SINGLE
537	Bs16	Organ Bass	SBS	66	89	—	—	1	SINGLE
538	Bs17	Garage Bass	SBS	66	90	—	—	1	SINGLE
539	Bs18	Attack Bass	SBS	66	91	—	—	5	DUAL
540	Bs19	House Bass 2	SBS	66	92	—	—	1	SINGLE
541	Bs20	SH-2 Bass	SBS	66	93	—	—	2	SINGLE
542	Bs21	MG Punch Bs	SBS	66	94	—	—	2	SINGLE
543	Bs22	MG Lite Bs	SBS	66	95	—	—	2	SINGLE
544	Bs23	PopSynthBass	SBS	66	96	—	—	2	SINGLE
545	Bs24	BriteSawBass	SBS	66	97	—	—	2	DUAL
546	Bs25	Mini Bass	SBS	66	98	—	—	1	SINGLE
547	Bs26	JU-2 Bass	SBS	66	99	—	—	1	SINGLE
548	Bs27	106 Bass 1	SBS	66	100	—	—	3	SINGLE
549	Bs28	106 Bass 2	SBS	66	101	—	—	1	SINGLE
550	Bs29	MG Bass 1	SBS	66	102	—	—	2	SINGLE
551	Bs30	MG Bass 2	SBS	66	103	—	—	2	SINGLE
552	Bs31	Unison Bs 1	SBS	66	104	—	—	2	SINGLE
553	Bs32	Unison Bs 2	SBS	66	105	—	—	3	SINGLE
554	Bs33	Unison Bs 3	SBS	66	106	—	—	3	SINGLE
555	Bs34	Unison Bs 4	SBS	66	107	—	—	2	SINGLE
556	Bs35	Unison Bs 5	SBS	66	108	—	—	4	SINGLE
557	Bs36	Detune Bass	SBS	66	109	—	—	3	SINGLE
558	Bs37	AEx Synth Bs	SBS	66	110	—	—	3	DUAL
559	Bs38	JUNO-D AcBs1	BS	66	111	—	—	2	SINGLE
560	Bs39	JUNO-D AcBs2	BS	66	112	—	—	2	SINGLE
561	Bs40	Upright Bs	BS	66	113	—	—	2	SINGLE
562	Bs41	JUNO-D Bs 1	BS	66	114	—	—	4	DUAL
563	Bs42	JUNO-D Bs 2	BS	66	115	—	—	2	SINGLE
564	Bs43	JUNO-D Bs 3	BS	66	116	—	—	2	SINGLE
565	Bs44	JUNO-DJazzBs	BS	66	117	—	—	2	SINGLE
566	Bs45	Bright Bass	BS	66	118	—	—	1	SINGLE
567	Bs46	JUNO-DRockBs	BS	66	119	—	—	2	SINGLE
568	Bs47	JUNO-DFlsBs1	BS	66	120	—	—	2	SINGLE
569	Bs48	JUNO-DFlsBs2	BS	66	121	—	—	2	SINGLE
570	Bs49	Mr.Smooth	BS	66	122	—	—	2	SINGLE
571	Bs50	JUNO-D Slap1	BS	66	123	—	—	1	SINGLE
572	Bs51	JUNO-D Slap2	BS	66	124	—	—	2	SINGLE
573	Bs52	AEx FingerBs	BS	66	125	—	—	3	DUAL
574	Bs53	Acoustic Bs.	BS	67	78	0	33	2	SINGLE
575	Bs54	Fingered Bs.	BS	67	79	0	34	1	SINGLE
576	Bs55	Finger Slap	BS	67	80	1	34	2	SINGLE
577	Bs56	Picked Bass	BS	67	81	0	35	1	SINGLE
578	Bs57	Fretless Bs.	BS	67	82	0	36	1	SINGLE
579	Bs58	Slap Bass 1	BS	67	83	0	37	1	SINGLE
580	Bs59	Slap Bass 2	BS	67	84	0	38	2	SINGLE
581	Bs60	Synth Bass 1	SBS	67	85	0	39	1	SINGLE
582	Bs61	SynthBass101	SBS	67	86	1	39	1	SINGLE
583	Bs62	Acid Bass	SBS	67	87	2	39	1	SINGLE
584	Bs63	Clavi Bass	SBS	67	88	3	39	2	SINGLE
585	Bs64	Hammer	SBS	67	89	4	39	2	SINGLE
586	Bs65	Synth Bass 2	SBS	67	90	0	40	2	SINGLE
587	Bs66	Beef FM Bass	SBS	67	91	1	40	2	SINGLE
588	Bs67	RubberBass 2	SBS	67	92	2	40	2	SINGLE
589	Bs68	Attack Pulse	SBS	67	93	3	40	1	SINGLE

## [0] RHYTHM &amp; SFX

No.	Name	Category	Patch Select		GM2 Patch Select		Voice	Key Mode	
			MSB = 87		MSB = 121				
			LSB	PC	LSB	PC			
Rh01-Rh20: Rhythm set list (p. 116)									
590	Rh21	W.Chime Down	PRC	66	126	—	—	1	SINGLE
591	Rh22	Nz & SawHit	SFX	66	127	—	—	2	SINGLE
592	Rh23	NylonGr Nz	SFX	66	128	—	—	1	SINGLE
593	Rh24	Timpani	PRC	67	103	0	48	1	SINGLE
594	Rh25	Agogo	PRC	68	76	0	114	1	SINGLE
595	Rh26	Woodblock	PRC	68	78	0	116	1	SINGLE
596	Rh27	Castanets	PRC	68	79	1	116	1	SINGLE
597	Rh28	Taiko	PRC	68	80	0	117	1	SINGLE
598	Rh29	Concert BD	PRC	68	81	1	117	1	SINGLE
599	Rh30	Melo. Tom 1	PRC	68	82	0	118	1	SINGLE
600	Rh31	Melo. Tom 2	PRC	68	83	1	118	1	SINGLE
601	Rh32	Synth Drum	PRC	68	84	0	119	2	SINGLE
602	Rh33	808 Tom	PRC	68	85	1	119	2	SINGLE
603	Rh34	Elec Perc	PRC	68	86	2	119	1	SINGLE
604	Rh35	Reverse Cym.	PRC	68	87	0	120	1	SINGLE
605	Rh36	Seashore	SFX	68	93	0	123	1	SINGLE
606	Rh37	Rain	SFX	68	94	1	123	1	SINGLE
607	Rh38	Thunder	SFX	68	95	2	123	1	SINGLE
608	Rh39	Wind	SFX	68	96	3	123	1	SINGLE
609	Rh40	Stream	SFX	68	97	4	123	2	SINGLE
610	Rh41	Bubble	SFX	68	98	5	123	2	SINGLE
611	Rh42	Bird	SFX	68	99	0	124	2	SINGLE
612	Rh43	Dog	SFX	68	100	1	124	1	SINGLE
613	Rh44	Horse-Gallop	SFX	68	101	2	124	1	SINGLE
614	Rh45	Bird 2	SFX	68	102	3	124	1	SINGLE
615	Rh46	Telephone 1	SFX	68	103	0	125	1	SINGLE
616	Rh47	Telephone 2	SFX	68	104	1	125	1	SINGLE
617	Rh48	DoorCreaking	SFX	68	105	2	125	1	SINGLE
618	Rh49	Door	SFX	68	106	3	125	1	SINGLE
619	Rh50	Scratch	SFX	68	107	4	125	1	SINGLE
620	Rh51	Wind Chimes	SFX	68	108	5	125	1	SINGLE
621	Rh52	Helicopter	SFX	68	109	0	126	1	SINGLE
622	Rh53	Car-Engine	SFX	68	110	1	126	1	SINGLE
623	Rh54	Car-Stop	SFX	68	111	2	126	1	SINGLE
624	Rh55	Car-Pass	SFX	68	112	3	126	1	SINGLE
625	Rh56	Car-Crash	SFX	68	113	4	126	2	SINGLE
626	Rh57	Siren	SFX	68	114	5	126	1	SINGLE
627	Rh58	Train	SFX	68	115	6	126	1	SINGLE
628	Rh59	Jetplane	SFX	68	116	7	126	2	SINGLE
629	Rh60	Starship	SFX	68	117	8	126	2	SINGLE
630	Rh61	Burst Noise	SFX	68	118	9	126	2	SINGLE
631	Rh62	Applause	SFX	68	119	0	127	2	SINGLE
632	Rh63	Laughing	SFX	68	120	1	127	1	SINGLE
633	Rh64	Screaming	SFX	68	121	2	127	1	SINGLE
634	Rh65	Punch	SFX	68	122	3	127	1	SINGLE
635	Rh66	Heart Beat	SFX	68	123	4	127	1	SINGLE
636	Rh67	Footsteps	SFX	68	124	5	127	1	SINGLE
637	Rh68	Gun Shot	SFX	68	125	0	128	1	SINGLE
638	Rh69	Machine Gun	SFX	68	126	1	128	1	SINGLE
639	Rh70	Lasergun	SFX	68	127	2	128	1	SINGLE
640	Rh71	Explosion	SFX	68	128	3	128	2	SINGLE

# Rhythm set list

	Rh01:Standard Kit (PC:001)	Voice	Rh02:Rock Kit (PC:002)	Voice	Rh03:Jazz Kit (PC:003)	Voice	Rh04:Brush Kit (PC:004)	Voice	Rh05:Orch Kit (PC:005)	Voice
16	----		----		----		----		----	
17	----		----		----		----		----	
18	----		----		----		----		----	
19	----		----		----		----		----	
20	----		----		----		----		----	
21	----		----		----		----		----	
22	----		----		----		----		----	
23	----		----		----		----		----	
C1 24	----		----		----		----		Tubular-bell	1
25	----		----		----		----		Tubular-bell	1
26	----		----		----		----		Tubular-bell	1
27	R&B Snr 1	2	JU-D Snr 3	2	Dry Snr 1	1	Dry Snr 2	1	Tubular-bell	1
28	Sharp Kick	2	Old Kick	2	Sharp Kick	2	Mix Kick	1	Tubular-bell	1
	Old Kick	2	Sharp Kick	2	Mix Kick	2	JazzDryKick2	2	Tubular-bell	1
29	JU-D Snr 4	2	JU-D Snr 4	2	Dry Snr 2	1	Jazz Rim	1	Tubular-bell	1
30	OldSharpKick	2	JU-D Kick 1	2	JazzDryKick1	2	JazzDryKick1	2	Tubular-bell	1
31	JU-D Snr 3	2	JU-D Snr 1	2	Brush Slap 1	1	JU-D JazzSnr	1	Tubular-bell	1
32	JU-D Kick 3	2	JU-D Kick 2	2	Jazz Kick 2	2	Jazz Kick 2	2	Tubular-bell	1
33	JU-D PHH	[EXC1] 1	JU-D PHH	[EXC1] 1	Jazz PHH	[EXC1] 1	Brush PHH	[EXC1] 1	Tubular-bell	1
34	JU-D Kick 1	2	Power Kick	1	Jazz Kick 3	2	Jazz Kick 1	1	Tubular-bell	1
C2 36	JU-D Kick 2	2	Hard Kick	3	JazzDryKick2	2	Jazz Kick 3	2	Concert BD	1
37	JU-D Stick	2	JU-D Stick	2	Dry Stick 1	1	Brush Slap 2	3	Side Stick	1
38	JU-D Snr 1	2	JU-D Snr 1	2	Jazz Rim	1	BrushSwirl 2	2	Concert Snr	1
39	Ghost&Flm	2	Ghost&Flm	2	SnareGhost	1	Brush Slap 1	1	TR909 Clap 1	1
40	JU-D Snr 2	2	Rock Snr	4	JU-D JazzSnr	1	BrushSwirl 1	1	Concert Snr	1
	JU-D Tom L	1	JU-D Tom L	1	JazzTom L	1	Brush Tom L	3	Timpani	1
41	JU-D CHH 3	[EXC1] 1	JU-D CHH 1	[EXC1] 1	JU-D CHH 1	[EXC1] 1	Brush CHH	[EXC1] 1	Timpani	1
42	JU-D TomLFlm	1	JU-D Tom L	1	JazzTomL/Flm	1	Brush Tom L	3	Timpani	1
43	JU-D CHH 4	[EXC1] 1	JU-D CHH 2	[EXC1] 1	JU-D CHH 2	[EXC1] 1	Brush PHH	[EXC1] 1	Timpani	1
44	JU-D Tom M	1	JU-D Tom M	1	JazzTom M	1	Brush Tom M	3	Timpani	1
45	JU-D OHH 2	[EXC1] 1	JU-D OHH 1	[EXC1] 1	JU-D OHH 1	[EXC1] 1	Brush OHH	[EXC1] 1	Timpani	1
46	JU-D TomMFlm	1	JU-D Tom M	1	JazzTomM/Flm	1	Brush Tom M	3	Timpani	1
C3 48	JU-D Tom H	1	JU-D Tom H	1	JazzTom H	1	Brush Tom H	3	Timpani	1
49	Crash Cym.3	2	Crash Cym.3	2	Jazz Crash	2	Brush Crash	1	Timpani	1
50	JU-D TomHFlm	1	JU-D Tom H	1	JazzTomH/Flm	1	Brush Tom H	3	Timpani	1
51	Rock Ride 1	1	Rock Ride 3	1	Jazz Ride 1	1	Jazz Ride 1	1	Timpani	1
52	ChinaCymbal2	2	ChinaCymbal2	2	ChinaCymbal1	1	ChinaCymbal1	1	Timpani	1
	Ride Bell 1	1	Rock Ride 2	1	Ride Bell 2	1	Ride Bell 1	1	Timpani	1
53	Tambourine 1	1	Tambourine 1	1	Tambourine 1	1	Tambourine 3	1	Tambourine 3	1
54	Splash Cym	1	ChinaCymbal2	2	Splash Cym	1	Splash Cym	1	Splash Cym	1
55	Cowbell	1	Cowbell	1	Cowbell	1	Cowbell	1	ChinaCymbal2	2
56	Rock Crash	2	Rock Crash	2	Crash Cym.2	1	Crash Cym.2	1	ConcertCym 1	1
57	Vibraslap	1	Vibraslap	1	Vibraslap	1	Vibraslap	1	Rev.Cymb 2	1
58	Rock Ride 2	1	Ride Cymbal	1	Jazz Ride 2	1	Jazz Ride 2	1	ConcertCym 2	2
C4 60	Bongo High 2	1	Bongo High 2	1	Bongo High 2	1	Bongo High 2	1	SlowAttackCym	1
61	Bongo Low 2	1	Bongo Low 2	1	Bongo Low 2	1	Bongo Low 2	1	SlowAttackCym	1
62	Conga Hi Mt2	[EXC2] 1	Conga Hi Mt2	[EXC2] 1	Conga Hi Mt2	[EXC2] 1	Conga Hi Mt2	[EXC2] 1	Taiko	1
63	CongHiOp/Slp	[EXC2] 1	CongHiOp/Slp	[EXC2] 1	CongHiOp/Slp	[EXC2] 1	CongHiOp/Slp	[EXC2] 1	CongHiOp/Slp	1
64	CongLwOp/Slp	1	CongLwOp/Slp	1	CongLwOp/Slp	1	CongLwOp/Slp	1	CongLwOp/Slp	1
	Timbale Hi 2	1	Timbale Hi 2	1	Timbale Hi 2	1	Timbale Hi 2	1	Timbale Hi 2	1
65	Timbale Lw 2	1	Timbale Lw 2	1	Timbale Lw 2	1	Timbale Lw 2	1	Timbale Lw 2	1
66	Agogo	1	Agogo	1	Agogo	1	Agogo	1	Agogo	1
67	Agogo	1	Agogo	1	Agogo	1	Agogo	1	Agogo	1
68	Cabasa	1	Cabasa	1	Cabasa	1	Cabasa	1	Cabasa	1
69	Maracas	1	Maracas	1	Maracas	1	Maracas	1	Maracas	1
70	ShortWhistle	[EXC3] 1	ShortWhistle	[EXC3] 1	ShortWhistle	[EXC3] 1	ShortWhistle	[EXC3] 1	ShortWhistle	[EXC3] 1
C5 72	LongWhistle2	[EXC3] 1	LongWhistle2	[EXC3] 1	LongWhistle2	[EXC3] 1	LongWhistle2	[EXC3] 1	LongWhistle2	[EXC3] 1
73	Guiro Short	[EXC4] 1	Guiro Sw	1	Guiro Sw	1	Guiro Sw	1	Cowbell	1
74	Guiro Long	[EXC4] 1	Castanets 2	2	Castanets 2	2	Castanets 2	2	Vibraslap	1
75	Claves	1	Claves	1	Claves	1	Claves	1	Claves	1
76	Woodblock	1	Woodblock	1	Woodblock	1	Woodblock	1	Woodblock	1
	Woodblock	1	Woodblock	1	Woodblock	1	Woodblock	1	Woodblock	1
77	Woodblock	1	Woodblock	1	Woodblock	1	Woodblock	1	Woodblock	1
78	Cuica Mute	[EXC5] 1	Cuica Sw	1	Cuica Sw	1	Cuica Sw	1	Castanets 2	2
79	Cuica Open	[EXC5] 1	Shaker Sw	1	Shaker Sw	1	Shaker Sw	1	Cuica Sw	1
80	Triangl Mt 1	[EXC6] 1	Triangl Mt 1	[EXC6] 1	Triangl Mt 1	[EXC6] 1	Triangl Mt 1	[EXC6] 1	Triangl Mt 1	[EXC6] 1
81	Triangl Op 1	[EXC6] 1	Triangl Op 1	[EXC6] 1	Triangl Op 1	[EXC6] 1	Triangl Op 1	[EXC6] 1	Triangl Op 1	[EXC6] 1
82	Shaker 1	1	Bell Tree	1	Bell Tree	1	Bell Tree	1	Shaker Sw	1
83	Jingle Bell	1	Jingle Bell	1	Jingle Bell	1	Jingle Bell	1	Jingle Bell	1
C6 84	WindChimeDwn	1	WindChimeDwn	1	WindChimeDwn	1	WindChimeDwn	1	Bell Tree	1
85	Castanets 2	2	W.ChimeShort	1	W.ChimeShort	1	W.ChimeShort	1	WindChimeDwn	1
86	Surdo Mute	[EXC7] 1	Surdo Mute	[EXC7] 1	Surdo Mute	[EXC7] 1	Surdo Mute	[EXC7] 1	W.ChimeShort	1
87	Surdo Open	[EXC7] 1	Surdo Open	[EXC7] 1	Surdo Open	[EXC7] 1	Surdo Open	[EXC7] 1	Bird 1	2
88	FingerSnap	1	FingerSnap	1	FingerSnap	1	FingerSnap	1	Church Bell	1
	TR909 Clap 2	1	TR909 Clap 2	1	TR909 Clap 1	1	TR909 Clap 1	1	Church Bell	1
89	Cheap Clap	1	TR808 Clap	1	TR808 Clap	1	TR808 Clap	1	FingerSnap	1
90	Bass Hit	2	Bass Hit	2	Bass Hit	2	Bass Hit	2	TR909 Clap 2	1
91	OrchestraHit	2	OrchestraHit	2	OrchestraHit	2	OrchestraHit	2	TR808 Clap	1
92	6th Hit	2	6th Hit	2	6th Hit	2	6th Hit	2	OrchestraHit	2
93	Euro Hit	2	Euro Hit	2	Applause	2	Applause	2	Applause	2
94	Mtrnm Click	1	Mtrnm Click	1	Mtrnm Click	1	Mtrnm Click	1	Mtrnm Click	1
C7 96	Mtrnm Bell	1	Mtrnm Bell	1	Mtrnm Bell	1	Mtrnm Bell	1	Mtrnm Bell	1
97	----		----		----		----		----	
98	----		----		----		----		----	
99	----		----		----		----		----	
100	----		----		----		----		----	

[EXC]: Percussion sound of the same number will not be heard at the same time.

PC: Program Number

Rh01-Rh05: MSB=086, LSB=064

# Rhythm set list

	Rh06:R&B/HHop Kit (PC:006)		Rh07:Techno Kit (PC:007)		Rh08:House Kit (PC:008)		Rh09:808&909 Kit (PC:009)		Rh10:Perc Menu (PC:010)	
		Voice		Voice		Voice		Voice		Voice
16	----		----		----		----		----	
17	----		----		----		----		----	
18	----		----		----		----		----	
19	----		----		----		----		----	
20	----		----		----		----		----	
21	----		----		----		----		----	
22	----		----		----		----		----	
23	----		----		----		----		----	
C1	----		----		----		----		----	
24	----		----		----		----		----	
25	----		----		----		----		----	
26	----		----		----		----		----	
27	Dry Snr 2	1	Elec Snare 2	2	R&B Snr 2	2	House Snr	1	Mtrnm Click	1
28	Sharp Kick	2	PlasticKick1	2	Old Kick	2	House Kick	2	Mtrnm Bell	1
29	Old Kick	2	House Kick	2	House Kick	2	SH32 Kick	2	Scratch 1	1
30	Jazz Flm	1	Elec Snare 1	1	TR808 Snr 2	1	Elec Snare 2	2	Scratch 2	1
31	TR909 Kick 2	1	SH32 Kick	2	SH32 Kick	2	PlasticKick1	2	Scratch Push	[EXC1] 1
32	JU-D JazzSnr	1	Finger Snr	1	Elec Snare 3	1	Elec Snare 3	1	Scratch Pull	[EXC1] 1
33	TechnoKick 1	2	TR909 Kick 1	1	TR909 Kick 2	1	TR808 Kick 1	1	ScratchPush2	[EXC2] 1
34	JU-D PHH	[EXC1] 1	TR909 PHH	[EXC1] 2	TR909 PHH	[EXC1] 2	TR909 PHH	[EXC1] 2	ScratchPull2	[EXC2] 1
35	R&B Kick 2	2	TR909 Kick 2	1	TechnoKick 1	2	TR808 Kick 2	1	Beam HiQ	1
C2	----		----		----		----		----	
36	R&B Kick 1	2	TechnoKick 1	2	PlasticKick1	2	TR808 Kick 3	1	Taiko	1
37	R&B Stick	3	TR909 Rim	1	Dry Stick 2	2	TR808 Rim	1	Surdo Mute	[EXC3] 1
38	R&B Snr 1	2	TR909 Snr 1	1	TR909 Snr 3	2	TR808 Snr 1	2	Surdo Open	[EXC3] 1
39	Cheap Clap	1	TR909 Clap 1	1	TR909 Clap 2	1	TR808 Clap	1	Bongo High 1	1
40	R&B Snr 2	2	TR909 Snr 2	1	House Snr	1	TR808 Snr 2	1	Bongo Low 1	1
41	R&B Tom L	1	TR909 Tom	1	TR909 Tom	1	TR808 Tom 2	1	Bongo High 2	1
42	JU-D CHH 5	[EXC1] 1	TR909 CHH 2	[EXC1] 1	TR909 CHH 2	[EXC1] 1	TR808 CHH 1	[EXC1] 1	Bongo Low 2	1
43	TR808 Kick 1	1	TR909 Tom	1	TR909 Tom	1	TR808 Tom	1	Conga Hi Mt	[EXC4] 1
44	JU-D CHH 6	[EXC1] 1	TR909 CHH 1	[EXC1] 1	TR909 CHH 1	[EXC1] 1	TR808 CHH 2	[EXC1] 1	CongaHi Open	[EXC4] 1
45	R&B Tom M	1	TR909 Tom	1	TR909 Tom	1	TR808 Tom 2	1	CongaLowOpen	1
46	JU-D OHH 3	[EXC1] 1	TR909 OHH	[EXC1] 1	TR909 OHH	[EXC1] 1	TR808 OHH	[EXC1] 1	Conga Hi Mt2	[EXC4] 1
47	TR808 Kick 1	1	TR909 Tom	1	TR909 Tom	1	TR808 Tom	1	CongHiOp/Slp	[EXC4] 1
C3	----		----		----		----		----	
48	R&B Tom H	1	TR909 Tom	1	TR909 Tom	1	TR808 Tom 2	1	CongLwOp/Slp	1
49	Crash Cym.3	2	TR909 Crash	1	TR909 Crash	1	TR808 Crash	1	TR808Conga 1	1
50	TR808 Kick 1	1	TR909 Tom	1	TR909 Tom	1	TR808 Tom	1	Timbale Hi 1	1
51	R&B Ride	1	TR909 Ride 1	1	TR909 Ride 2	1	TR909 Ride 3	1	Timbale Lw 1	1
52	TR808 Crash	1	ChinaCymbal2	2	ChinaCymbal2	2	TR909 Splash	1	Timbale Hi 2	1
53	TR909RideB11	1	TR909RideB12	1	TR909RideB11	1	TR909RideB12	1	Timbale Lw 2	1
54	Tambourine 1	1	Tambourine 2	1	Tambourine 3	1	TR808Conga 1	1	Cuica Mute	[EXC5] 1
55	TR909 Splash	1	NoiseCymbal	1	TR909 Splash	1	TR909 Splash	1	Cuica Open	[EXC5] 1
56	TR808Cowbell	1	TR808Cowbell	1	Cowbell	1	TR808Cowbell	1	Cuica Sw	1
57	TR909 Crash	1	TR808 Crash	1	TR808 Crash	1	TR808 Crash	1	Castanets	1
58	Vibraslap	1	Vibraslap	1	Vibraslap	1	TR909 PHH	[EXC1] 2	Castanets 2	2
59	TR909 Ride 2	1	TR909 Ride 3	1	TR909 Ride 3	1	TR909 Kick 1	1	Tambourine 1	1
C4	----		----		----		----		----	
60	Bongo High 2	1	Bongo High 2	1	Bongo High 2	1	TR909 Kick 2	1	Tambourine 2	1
61	Bongo Low 2	1	Bongo Low 2	1	Bongo Low 2	1	TR909 Rim	1	Tambourine 3	1
62	Conga Hi Mt2	[EXC2] 1	TR808Conga 1	1	Conga Hi Mt2	[EXC2] 1	TR909 Snr 1	1	Cabasa	1
63	CongHiOp/Slp	[EXC2] 1	CongHiOp/Slp	1	CongHiOp/Slp	[EXC2] 1	TR909 Clap 2	1	Maracas	1
64	CongLwOp/Slp	[EXC2] 1	CongLwOp/Slp	1	CongLwOp/Slp	1	TR909 Snr 2	1	TR808Maracas	1
65	Timbale Hi 2	1	Timbale Hi 2	1	Timbale Hi 2	1	TR909 Tom	1	Claves	1
66	Timbale Lw 2	1	Timbale Lw 2	1	Timbale Lw 2	1	TR909 CHH 1	[EXC1] 1	TR808 Clave	1
67	Agogo	1	Agogo	1	Agogo	1	TR909 Tom	1	Woodblock	1
68	Agogo	1	Agogo	1	Agogo	1	TR909 CHH 2	[EXC1] 1	Woodblock	1
69	Cabasa	1	Cabasa	1	Cabasa	1	TR909 Tom	1	Cowbell	1
70	Maracas	1	TR808Maracas	1	Maracas	1	TR909 OHH	[EXC1] 1	TR808Cowbell	1
71	ShortWhistle	[EXC3] 1	ShortWhistle	[EXC3] 1	ShortWhistle	[EXC3] 1	TR909 Tom	1	Vibraslap	1
C5	----		----		----		----		----	
72	LongWhistle2	[EXC3] 1	LongWhistle2	[EXC3] 1	LongWhistle2	[EXC3] 1	TR909 Tom	1	Shaker 1	[EXC6] 1
73	Shaker Sw	1	Cuica Sw	1	Guiro Short	[EXC4] 1	TR909 Crash	1	Shaker 2	[EXC6] 1
74	Cuica Sw	1	Shaker Sw	1	Guiro Long	[EXC4] 1	TR909 Tom	1	Shaker Sw	1
75	Castanets 2	2	TR808 Clave	1	Shaker 2	1	TR909 Ride 1	1	Guiro Short	[EXC7] 1
76	Triangl Mt 2	[EXC6] 1	Guiro Sw	1	Castanets	1	ChinaCymbal2	2	Guiro Long	[EXC7] 1
77	Triangl Op 2	[EXC6] 1	Castanets 2	2	TR808 Clave	1	TR909RideB11	1	Guiro Sw	1
78	Bell Tree	1	Triangl Mt 1	[EXC6] 1	Cuica Mute	[EXC5] 1	TR808Maracas	1	Triangl Mt 1	[EXC8] 1
79	Jingle Bell	1	Triangl Op 1	[EXC6] 1	Cuica Open	[EXC5] 1	TR909 Splash	1	Triangl Op 1	[EXC8] 1
80	WindChimeDwn	1	Jingle Bell	1	Bell Tree	1	TR808Cowbell	1	Triangl Mt 2	[EXC9] 1
81	Surdo Mute	[EXC7] 1	Surdo Mute	[EXC7] 1	Surdo Mute	[EXC7] 1	TR909 Crash	1	Triangl Op 2	[EXC9] 1
82	Surdo Open	[EXC7] 1	Surdo Open	[EXC7] 1	Surdo Open	[EXC7] 1	TR808 Clave	1	Agogo	1
83	FingerSnap	1	FingerSnap	1	FingerSnap	1	TR909 Ride 2	1	Agogo	1
C6	----		----		----		----		----	
84	TR909 Clap 2	1	TR909 Clap 2	1	TR909 Clap 1	1	NoiseCymbal	1	ShortWhistle	[EXC10] 1
85	TR808 Clap	1	TR808 Clap	1	TR808 Clap	1	TR909 Clap 1	1	Long Whistle	[EXC10] 1
86	TR909 Clap 1	1	Rev.909Crash	1	Rev.909Crash	1	TR909 Clap 2	1	LongWhistle2	[EXC10] 1
87	ScratchPush2	[EXC8] 1	Rev.909 OHH	1	Rev.909 OHH	1	TR808 Clap	1	FingerSnap	1
88	ScratchPull2	[EXC8] 1	Rev.909Kick2	1	Rev.909Kick2	1	Rev.909Kick2	1	Cheap Clap	1
89	Scratch Push	[EXC9] 1	Rev.909HClap	1	Rev.909HClap	1	Rev.909Crash	1	TR909 Clap 1	1
90	Scratch Pull	[EXC9] 1	Beam HiQ	1	Beam HiQ	1	Rev.909 OHH	1	TR909 Clap 2	1
91	Scratch 2	1	Techno Hit	1	Techno Hit	1	Rev.909HClap	1	TR808 Clap	1
92	Rev.909HClap	1	Bass Hit	2	Bass Hit	2	Square Click	1	Jingle Bell	1
93	Philly Hit	1	6th Hit	2	6th Hit	2	High-Q	1	Bell Tree	1
94	Siren	1	Euro Hit	2	Euro Hit	2	Beam HiQ	1	W.ChimeShort	1
95	Mtrnm Click	1	MC500 Beep 2	1	MC500 Beep 2	1	MC500 Beep 2	1	WindChimeDwn	1
C7	----		----		----		----		----	
96	Mtrnm Bell	1	MC500 Beep 1	1	MC500 Beep 1	1	MC500 Beep 1	1	Church Bell	1
97	----		----		----		----		----	
98	----		----		----		----		----	
99	----		----		----		----		----	
100	----		----		----		----		----	

[EXC]: Percussion sound of the same number will not be heard at the same time.

PC: Program Number

Rh06–Rh10: MSB=086, LSB=064

# Rhythm set list

Rh11:Drums Menu (PC:011)		Rh12:GM2 STANDARD (PC:001)		Rh13:GM2 ROOM (PC:009)		Rh14:GM2 POWER (PC:017)		Rh15:GM2 ELECTRIC (PC:025)	
	Voice		Voice		Voice		Voice		Voice
16	----	----		----		----		----	
17	----	----		----		----		----	
18	----	----		----		----		----	
19	----	----		----		----		----	
20	----	----		----		----		----	
21	JU-D Kick 1	2	----	----		----		----	
22	JU-D Kick 2	2	----	----		----		----	
23	JU-D Kick 3	2	----	----		----		----	
C1 24	StandardKick	1	----	----		----		----	
25	Jazz Kick 1	1	----	----		----		----	
26	Jazz Kick 2	2	----	----		----		----	
27	Jazz Kick 3	2	High-Q	1	High-Q	1	High-Q	1	High-Q
28	JazzDryKick1	2	Slap	1	Slap	1	Slap	1	Slap
29	JazzDryKick2	2	Scratch Push	[EXC7]	1	Scratch Push	[EXC7]	1	Scratch Push
30	Mix Kick	1	Scratch Pull	[EXC7]	1	Scratch Pull	[EXC7]	1	Scratch Pull
31	Power Kick	1	Sticks	1	Sticks	1	Sticks	1	Sticks
32	Hard Kick	3	Square Click	1	Square Click	1	Square Click	1	Square Click
33	R&B Kick 1	2	Mtrnm Click	1	Mtrnm Click	1	Mtrnm Click	1	Mtrnm Click
34	R&B Kick 2	2	Mtrnm Bell	1	Mtrnm Bell	1	Mtrnm Bell	1	Mtrnm Bell
35	OldSharpKick	2	Mix Kick	1	Mix Kick	1	Mix Kick	1	Mix Kick
C2 36	Sharp Kick	2	StandardKick	1	StandardKick	1	Power Kick	1	Elec Kick
37	Old Kick	2	Side Stick	1	Side Stick	1	Side Stick	1	Side Stick
38	SH32 Kick	2	Standard Snr	1	Standard Snr	1	Dance Snare	1	Elec Snare 1
39	TechnoKick 1	2	TR909 Clap 1	1	TR909 Clap 1	1	TR909 Clap 1	1	TR909 Clap 1
40	TR909 Kick 1	1	Elec Snare 3	1	Elec Snare 3	1	Elec Snare 3	1	Elec Snare 2
41	TR909 Kick 2	1	Room Tom 3	1	Room Tom 2	1	Rock Tom 2	1	Synth Drum
42	Elec Kick	2	Close HiHat	[EXC1]	1	Close HiHat	[EXC1]	1	Close HiHat
43	TR808 Kick 1	1	Room Tom 3	1	Room Tom 2	1	Rock Tom 2	1	Synth Drum
44	TR808 Kick 2	1	Standard PHH	[EXC1]	1	Standard PHH	[EXC1]	1	Standard PHH
45	TR808 Kick 3	1	Room Tom 2	1	Room Tom 1	1	Rock Tom 2	1	Synth Drum
46	House Kick	2	Standard OHH	[EXC1]	1	Standard OHH	[EXC1]	1	Standard OHH
47	PlasticKick1	2	Room Tom 2	1	Room Tom 1	1	Rock Tom 2	1	Synth Drum
C3 48	PlasticKick2	1	Room Tom 1	1	Room Tom 1	1	Rock Tom 1	1	Synth Drum
49	JU-D Snr 1	2	Crash Cym.1	1	Crash Cym.1	1	Crash Cym.1	1	Crash Cym.1
50	JU-D Snr 2	2	Room Tom 1	1	Room Tom 1	1	Rock Tom 1	1	Synth Drum
51	JU-D Snr 3	2	Ride Cymbal	1	Ride Cymbal	1	Ride Cymbal	1	Ride Cymbal
52	JU-D Snr 4	2	ChinaCymbal1	1	ChinaCymbal1	1	ChinaCymbal1	1	Rev.Cymb1 1
53	Standard Snr	1	Ride Bell 2	1	Ride Bell 2	1	Ride Bell 2	1	Ride Bell 2
54	Rock Snr	4	Tambourine 3	1	Tambourine 3	1	Tambourine 3	1	Tambourine 3
55	JU-D JazzSnr	1	Splash Cym	1	Splash Cym	1	Splash Cym	1	Splash Cym
56	Jazz Snr	1	Cowbell	1	Cowbell	1	Cowbell	1	Cowbell
57	Brush Slap 1	1	Crash Cym.2	1	Crash Cym.2	1	Crash Cym.2	1	Crash Cym.2
58	Brush Slap 2	3	Vibraslap	1	Vibraslap	1	Vibraslap	1	Vibraslap
59	BrushSwirl 1	1	Ride Cymbal	1	Ride Cymbal	1	Ride Cymbal	1	Ride Cymbal
C4 60	BrushSwirl 2	2	Bongo High 1	1	Bongo High 1	1	Bongo High 1	1	Bongo High 1
61	R&B Snr 1	2	Bongo Low 1	1	Bongo Low 1	1	Bongo Low 1	1	Bongo Low 1
62	R&B Snr 2	2	Conga Hi Mt	1	Conga Hi Mt	1	Conga Hi Mt	1	Conga Hi Mt
63	Dry Snr 1	1	CongaHi Open	1	CongaHi Open	1	CongaHi Open	1	CongaHi Open
64	Dry Snr 2	1	CongaLowOpen	1	CongaLowOpen	1	CongaLowOpen	1	CongaLowOpen
65	TR909 Snr 1	1	Timbale Hi 1	1	Timbale Hi 1	1	Timbale Hi 1	1	Timbale Hi 1
66	TR909 Snr 2	1	Timbale Lw 1	1	Timbale Lw 1	1	Timbale Lw 1	1	Timbale Lw 1
67	TR909 Snr 3	2	Agogo	1	Agogo	1	Agogo	1	Agogo
68	TR808 Snr 1	2	Agogo	1	Agogo	1	Agogo	1	Agogo
69	TR808 Snr 2	1	Cabasa	1	Cabasa	1	Cabasa	1	Cabasa
70	House Snr	1	Maracas	1	Maracas	1	Maracas	1	Maracas
71	Finger Snr	1	ShortWhistle	[EXC2]	1	ShortWhistle	[EXC2]	1	ShortWhistle
C5 72	Dance Snare	1	Long Whistle	[EXC2]	1	Long Whistle	[EXC2]	1	Long Whistle
73	Elec Snare 1	1	Guiro Short	[EXC3]	1	Guiro Short	[EXC3]	1	Guiro Short
74	Elec Snare 2	2	Guiro Long	[EXC3]	1	Guiro Long	[EXC3]	1	Guiro Long
75	Elec Snare 3	1	Claves	1	Claves	1	Claves	1	Claves
76	Jazz Rim	1	Woodblock	1	Woodblock	1	Woodblock	1	Woodblock
77	JU-D Stick	2	Woodblock	1	Woodblock	1	Woodblock	1	Woodblock
78	Dry Stick 1	1	Cuica Mute	[EXC4]	1	Cuica Mute	[EXC4]	1	Cuica Mute
79	Dry Stick 2	2	Cuica Open	[EXC4]	1	Cuica Open	[EXC4]	1	Cuica Open
80	R&B Stick	3	Triangl Mt 1	[EXC5]	1	Triangl Mt 1	[EXC5]	1	Triangl Mt 1
81	Sticks	1	Triangl Op 1	[EXC5]	1	Triangl Op 1	[EXC5]	1	Triangl Op 1
82	Side Stick	1	Shaker 1	1	Shaker 1	1	Shaker 1	1	Shaker 1
83	TR909 Rim	1	Jingle Bell	1	Jingle Bell	1	Jingle Bell	1	Jingle Bell
C6 84	TR808 Rim	1	Bell Tree	1	Bell Tree	1	Bell Tree	1	Bell Tree
85	JU-D CHH 1	[EXC1]	Castanets	1	Castanets	1	Castanets	1	Castanets
86	JU-D CHH 2	[EXC1]	Surdo Mute	[EXC6]	1	Surdo Mute	[EXC6]	1	Surdo Mute
87	JU-D CHH 3	[EXC1]	Surdo Open	[EXC6]	1	Surdo Open	[EXC6]	1	Surdo Open
88	JU-D CHH 4	[EXC1]	----	----	----	----	----	----	----
89	JU-D CHH 5	[EXC1]	----	----	----	----	----	----	----
90	JU-D CHH 6	[EXC1]	----	----	----	----	----	----	----
91	Close HiHat	[EXC1]	----	----	----	----	----	----	----
92	Brush CHH	[EXC1]	----	----	----	----	----	----	----
93	TR909 CHH 1	[EXC1]	----	----	----	----	----	----	----
94	TR909 CHH 2	[EXC1]	----	----	----	----	----	----	----
95	TR808 CHH 1	[EXC1]	----	----	----	----	----	----	----
C7 96	TR808 CHH 2	[EXC1]	----	----	----	----	----	----	----
97	JU-D OHH 1	[EXC1]	----	----	----	----	----	----	----
98	JU-D OHH 2	[EXC1]	----	----	----	----	----	----	----
99	JU-D OHH 3	[EXC1]	----	----	----	----	----	----	----
100	Standard OHH	[EXC1]	----	----	----	----	----	----	----
101	Brush OHH	[EXC1]	----	----	----	----	----	----	----
102	TR909 OHH	[EXC1]	----	----	----	----	----	----	----
103	TR808 OHH	[EXC1]	----	----	----	----	----	----	----
104	JU-D PHH	[EXC1]	----	----	----	----	----	----	----
105	Jazz PHH	[EXC1]	----	----	----	----	----	----	----
106	Brush PHH	[EXC1]	----	----	----	----	----	----	----
107	TR909 PHH	[EXC1]	----	----	----	----	----	----	----

[EXC]: Percussion sound of the same number will not be heard at the same time.

PC: Program Number

Rh11: MSB=086, LSB=064

Rh12-Rh15: MSB=120, LSB=000

# Rhythm set list

	Rh16:GM2 ANALOG (PC:026)	Voice	Rh17:GM2 JAZZ (PC:033)	Voice	Rh18:GM2 BRUSH (PC:041)	Voice	Rh19:GM2 ORCHSTRA (PC:049)	Voice	Rh20:GM2 SFX (PC:057)	Voice
16	----		----		----		----		----	
17	----		----		----		----		----	
18	----		----		----		----		----	
19	----		----		----		----		----	
20	----		----		----		----		----	
21	----		----		----		----		----	
22	----		----		----		----		----	
23	----		----		----		----		----	
C1 24	----		----		----		----		----	
25	----		----		----		----		----	
26	----		----		----		----		----	
27	High-Q	1	High-Q	1	High-Q	1	Close HIHat	[EXC1] 1	----	
28	Slap	1	Slap	1	Slap	1	Standard PHH	[EXC1] 1	----	
29	Scratch Push	[EXC7] 1	Scratch Push	[EXC7] 1	Scratch Push	[EXC7] 1	Standard OHH	[EXC1] 1	----	
30	Scratch Pull	[EXC7] 1	Scratch Pull	[EXC7] 1	Scratch Pull	[EXC7] 1	Ride Cymbal	1	----	
31	Sticks	1	Sticks	1	Sticks	1	Sticks	1	----	
32	Square Click	1	Square Click	1	Square Click	1	Square Click	1	----	
33	Mtrnm Click	1	Mtrnm Click	1	Mtrnm Click	1	Mtrnm Click	1	----	
34	Mtrnm Bell	1	Mtrnm Bell	1	Mtrnm Bell	1	Mtrnm Bell	1	----	
35	Mix Kick	1	Jazz Kick 2	2	Jazz Kick 2	2	Concert BD	1	----	
C2 36	TR808 Kick 1	1	Jazz Kick 1	1	Jazz Kick 1	1	ConcertBD Mt	1	----	
37	TR808 Rim	1	Side Stick	1	Side Stick	1	Side Stick	1	----	
38	TR808 Snr 2	1	Jazz Snr	1	BrushSwirl 2	2	Concert Snr	1	----	
39	TR909 Clap 1	1	TR909 Clap 1	1	Brush Slap 1	1	Castanets	1	High-Q	1
40	Elec Snare 3	1	Elec Snare 3	1	BrushSwirl 1	1	Concert Snr	1	Slap	1
41	TR808 Tom 2	1	Real Tom 3	1	Real Tom 3	1	Timpani	1	Scratch Push	[EXC7] 1
42	TR808 CHH 2	[EXC1] 1	Close HIHat	[EXC1] 1	Brush CHH	[EXC1] 1	Timpani	1	Scratch Pull	[EXC7] 1
43	TR808 Tom 2	1	Real Tom 3	1	Real Tom 3	1	Timpani	1	Sticks	1
44	TR808 CHH 1	[EXC1] 1	Standard PHH	[EXC1] 1	Brush PHH	[EXC1] 1	Timpani	1	Square Click	1
45	TR808 Tom 2	1	Real Tom 2	1	Real Tom 2	1	Timpani	1	Mtrnm Click	1
46	TR808 OHH	[EXC1] 1	Standard OHH	[EXC1] 1	Brush OHH	[EXC1] 1	Timpani	1	Mtrnm Bell	1
47	TR808 Tom 2	1	Real Tom 2	1	Real Tom 2	1	Timpani	1	Gt.FretNoise	1
C3 48	TR808 Tom 2	1	Real Tom 1	1	Real Tom 1	1	Timpani	1	Gt.CutNoise	1
49	TR808 Crash	1	Crash Cym.1	1	Brush Crash	1	Timpani	1	Gt.CutNoise	1
50	TR808 Tom 2	1	Real Tom 1	1	Real Tom 1	1	Timpani	1	String Slap	1
51	Ride Cymbal	1	Ride Cymbal	1	Ride Cymbal	1	Timpani	1	Fl.KeyClick	1
52	ChinaCymbal1	1	ChinaCymbal1	1	ChinaCymbal1	1	Timpani	1	Laughing	1
53	Ride Bell 2	1	Ride Bell 2	1	Ride Bell 2	1	Timpani	1	Screaming	1
54	Tambourine 3	1	Tambourine 3	1	Tambourine 3	1	Tambourine 3	1	Punch	1
55	Splash Cym	1	Splash Cym	1	Splash Cym	1	Splash Cym	1	Heart Beat	1
56	TR808Cowbell	1	Cowbell	1	Cowbell	1	Cowbell	1	Footsteps	1
57	Crash Cym.2	1	Crash Cym.2	1	Crash Cym.2	1	ConcertCym 1	1	Footsteps	1
58	Vibraslap	1	Vibraslap	1	Vibraslap	1	Vibraslap	1	Applause	2
59	Ride Cymbal	1	Ride Cymbal	1	Ride Cymbal	1	ConcertCym 2	2	Creaking	1
C4 60	Bongo High 1	1	Bongo High 1	1	Bongo High 1	1	Bongo High 1	1	Door	1
61	Bongo Low 1	1	Bongo Low 1	1	Bongo Low 1	1	Bongo Low 1	1	Scratch 1	1
62	TR808Conga 1	1	Conga Hi Mt	1	Conga Hi Mt	1	Conga Hi Mt	1	Wind Chimes	1
63	TR808Conga 1	1	CongaHi Open	1	CongaHi Open	1	CongaHi Open	1	Car-Engine	1
64	TR808Conga 1	1	CongaLowOpen	1	CongaLowOpen	1	CongaLowOpen	1	Car-Stop	1
65	Timbale Hi 1	1	Timbale Hi 1	1	Timbale Hi 1	1	Timbale Hi 1	1	Car-Pass	1
66	Timbale Lw 1	1	Timbale Lw 1	1	Timbale Lw 1	1	Timbale Lw 1	1	Car-Crash	2
67	Agogo	1	Agogo	1	Agogo	1	Agogo	1	Siren	1
68	Agogo	1	Agogo	1	Agogo	1	Agogo	1	Train	1
69	Cabasa	1	Cabasa	1	Cabasa	1	Cabasa	1	Jetplane	2
70	TR808Maracas	1	Maracas	1	Maracas	1	Maracas	1	Helicopter	1
71	ShortWhistle	[EXC2] 1	ShortWhistle	[EXC2] 1	ShortWhistle	[EXC2] 1	ShortWhistle	[EXC2] 1	Starship	2
C5 72	Long Whistle	[EXC2] 1	Long Whistle	[EXC2] 1	Long Whistle	[EXC2] 1	Long Whistle	[EXC2] 1	Gun Shot	1
73	Guiro Short	[EXC3] 1	Guiro Short	[EXC3] 1	Guiro Short	[EXC3] 1	Guiro Short	[EXC3] 1	Machine Gun	1
74	Guiro Long	[EXC3] 1	Guiro Long	[EXC3] 1	Guiro Long	[EXC3] 1	Guiro Long	[EXC3] 1	Lasergun	1
75	TR808 Clave	1	Claves	1	Claves	1	Claves	1	Explosion	2
76	Woodblock	1	Woodblock	1	Woodblock	1	Woodblock	1	Dog	1
77	Woodblock	1	Woodblock	1	Woodblock	1	Woodblock	1	Horse-Gallop	1
78	Cuica Mute	[EXC4] 1	Cuica Mute	[EXC4] 1	Cuica Mute	[EXC4] 1	Cuica Mute	[EXC4] 1	Bird 1	2
79	Cuica Open	[EXC4] 1	Cuica Open	[EXC4] 1	Cuica Open	[EXC4] 1	Cuica Open	[EXC4] 1	Rain	1
80	Triangl Mt 1	[EXC5] 1	Triangl Mt 1	[EXC5] 1	Triangl Mt 1	[EXC5] 1	Triangl Mt 1	[EXC5] 1	Thunder	1
81	Triangl Op 1	[EXC5] 1	Triangl Op 1	[EXC5] 1	Triangl Op 1	[EXC5] 1	Triangl Op 1	[EXC5] 1	Wind	1
82	Shaker 1	1	Shaker 1	1	Shaker 1	1	Shaker 1	1	Seashore	1
83	Jingle Bell	1	Jingle Bell	1	Jingle Bell	1	Jingle Bell	1	Stream	2
C6 84	Bell Tree	1	Bell Tree	1	Bell Tree	1	Bell Tree	1	Bubble	2
85	Castanets	1	Castanets	1	Castanets	1	Castanets	1	----	
86	Surdo Mute	[EXC6] 1	Surdo Mute	[EXC6] 1	Surdo Mute	[EXC6] 1	Surdo Mute	[EXC6] 1	----	
87	Surdo Open	[EXC6] 1	Surdo Open	[EXC6] 1	Surdo Open	[EXC6] 1	Surdo Open	[EXC6] 1	----	
88	----		----		----		Applause	2	----	
89	----		----		----		----		----	
90	----		----		----		----		----	
91	----		----		----		----		----	
92	----		----		----		----		----	
93	----		----		----		----		----	
94	----		----		----		----		----	
95	----		----		----		----		----	

[EXC]: Percussion sound of the same number will not be heard at the same time.

PC: Program Number

Rh16-Rh20: MSB=120, LSB=000