

OCTAPAD SPD-30 Instrument List

No.	Name
KIK: Kick (bass drum)	
001	Tight Kick
002	Alt Kick
003	Fiber Kick
004	Birch Kick
005	RockVintage Kick
006	Deep Kick
007	20"Kick
008	Vintage Kick
009	Hard Kick
010	Meat Kick
011	NuHip Kick
012	Solid Kick
013	BB Kick
014	Hybrid Kick
015	Impact Kick
016	Elec Kick 1
017	Elec Kick 2
018	78 Kick
019	110 Kick
020	808 Kick
021	909 Kick 1
022	909 Kick 2
023	Kick Ambience
SNR: Snare drum	
001	Wood Snare
002	Wood Snare Rim
003	Wood Snare Xstk
004	Tight Snare
005	Tight Snare Rim
006	Tight Snare Xstk
007	Alt Snare
008	Alt Snare Rim
009	Alt Snare Xstk
010	12"Snare
011	12"Snare Rim
012	12"Snare Xstk
013	Brass Snare
014	Brass Snare Rim
015	Brass Snare Xstk
016	Loose Snare
017	Loose Snare Rim
018	Loose Snare Xstk
019	Brush Snare
020	Brush Snare Tap
021	Brush Snare Roll

No.	Name
022	March Snare
023	March Snare Rim
024	March Rim Click
025	Field Snare
026	Field Snare Rim
027	Field Rim Click
028	NuJack Snare
029	LiteClub Snare
030	2step Snare
031	BB Snare
032	Box Snare
033	Club Snare 1
034	Club Snare 2
035	Barrel Snare 1
036	Barrel Snare 2
037	Whack Snare
038	Elec Snare
039	78 Snare
040	110 Snare
041	606 Snare
042	707 Snare
043	808 Snare 1
044	808 Snare 2
045	909 Snare
046	909 Snare n Clap
047	78 Rim
048	808 Rim
049	909 Rim
050	Snare Ambience
TOM: Tom-tom	
001	10"Wood Tom
002	12"Wood Tom
003	14"Wood Tom
004	16"Wood Tom
005	10"Lite Tom
006	12"Lite Tom
007	13"Lite Tom
008	16"Lite Tom
009	12"Birch Tom
010	14"Birch Tom
011	16"Birch Tom
012	10"Coated Tom
013	12"Coated Tom
014	14"Coated Tom
015	10"Brush Tom
016	12"Brush Tom
017	14"Brush Tom

No.	Name
018	12"Rock Tom
019	13"Rock Tom
020	16"Rock Tom
021	12"Ambient Tom
022	14"Ambient Tom
023	16"Ambient Tom
024	6"Roto Tom
025	8"Roto Tom
026	10"Roto Tom
027	12"Roto Tom
028	6"Quad Tom
029	10"Quad Tom
030	12"Quad Tom
031	13"Quad Tom
032	14"Quad Tom
033	ElecTom 1
034	ElecTom 2
035	808Tom
036	909Tom
037	Tom Ambience
HH: Hi-hat cymbal	
001	Med Hihat Bow
002	Med Hihat Edge
003	Dark Hihat Bow
004	Dark Hihat Edge
005	House Hihat Bow
006	House Hihat Edge
007	Brush Hihat
008	Spoke HH
009	78 HH
010	808 HH
011	909 HH
RD: Ride cymbal	
001	Medium Ride Bow
002	Medium Ride Bell
003	Medium Ride Edge
004	Jazz Ride Bow
005	Jazz Ride Bell
006	Jazz Ride Edge
007	Clear Ride Bow
008	Clear Ride Bell
009	Clear Ride Edge
010	Brush Ride Bow
011	Brush Ride Bell
012	Brush Ride Edge
013	Sizzle Ride Bow

No.	Name
014	Sizzle Ride Bell
015	Sizzle Ride Edge
CYM: Miscellaneous cymbal	
001	16"Thin Bow
002	16"Thin Edge
003	17"Medium Bow
004	17"Medium Edge
005	18"Dark Bow
006	18"Dark Edge
007	18"Suspend Bow
008	18"Suspend Edge
009	16"Brush
010	18"Brush
011	18"Brush Sizzle
012	6"Splash
013	8"Splash
014	10"Splash
015	13"Latin Crash
016	14"FX Crash
017	16"China Cymbal
018	18"Swish Cymbal
019	3 Layered Crash
020	4"Accent Cymbal
021	6"Chime Cymbal
022	6"Cross Cymbal
023	8"Cross Cymbal
024	18"Piatti1
025	18"Piatti1 Smash
026	18"Piatti2
027	18"Piatti2 Choke
028	18"Piatti2 Scrpce
029	606 Cymbal
030	808 Cymbal
PC1: Percussion with heads	
001	Timbale H Open
002	Timbale H Rim
003	Timbale H Paila
004	Timbale L Open
005	Timbale L Hand
006	Timbale L HandMt
007	Timbale L Paila
008	Bongo H Open
009	Bongo H Slap
010	Bongo H MuteSlap
011	Bongo L Open
012	Bongo L Slap

OCTAPAD SPD-30 Instrument List

No.	Name	No.	Name	No.	Name	No.	Name
013	Conga H Open	060	Repinique Mute	107	Dawul Buzz	154	Cajon 2 Open
014	Conga H Slap	061	Repinique Rim	108	Framedrum S Open	155	Cajon 2 Close
015	Conga H Mute	062	Caixa	109	Framedrum S Edge	156	Cajon 2 Slap
016	Conga H MuteSlap	063	Surdo Open	110	Framedrum S Mute	157	Cajon 2 Bass
017	Conga H Bass	064	Surdo Mute	111	Framedrum S Scrp	158	Potdrum Open L
018	Conga H Heel	065	Surdo Rim	112	Framedrum S Harm	159	Potdrum Open R
019	Conga H Toe	066	Tabla Na	113	Framedrum L Open	160	Potdrum Heel
020	Conga H Heel/Toe	067	Tabla Te	114	Framedrum L Edge	161	Potdrum Hole S
021	Conga H Gliss	068	Tabla Ti	115	Framedrum L Mute	162	Potdrum Hole L
022	Conga L Open	069	Tabla Tin	116	Framedrum L Scrp	163	Potdrum Bottom
023	Conga L Slap	070	Tabla Tun	117	Framedrum L Harm	164	Potdrum Gliss
024	Conga L Bass	071	Baya Ga	118	Tambourine 1	165	Ipu Body
025	Conga L Gliss	072	Baya Ge	119	Tambourine 2	166	Ipu Slap
026	Djembe Open	073	Baya Ge Mute	120	Tambourine Roll	167	Ipu Hole
027	Djembe OpenSlap	074	Baya Ge Slide	121	Tambourine Stick	168	Ipu Stomp
028	Djembe MuteSlap	075	Baya Gin	122	Tambour	169	8"Water Drum
029	Djembe Basstone	076	Baya Ka	123	Tambour Rim	170	10"Water Drum
030	Djembe Ears	077	Dholak Ga	124	Bombo	171	12"Water Drum
031	Kenkeni Open	078	Dholak Ta	125	Bombo Rim	172	14"Water Drum
032	Kenkeni Mute	079	Dholak Tun	126	Buk	173	16"Water Drum
033	Kenkeni Rim	080	Dholak Na	127	Buk Rim		
034	Sangban Open	081	Dhol Beater	128	Jang Gu	PC2:	Metallic percussion
035	Sangban Mute	082	Dhol Hand	129	Jang Gu Stick	001	Cowbell 1
036	Sangban Rim	083	Dhol Body	130	Ban Gu	002	Cowbell 2
037	Doumdoumba Open	084	Dhol Stick	131	Ban Gu Edge	003	Cowbell 3
038	Doumdoumba Mute	085	Madal Da	132	Tang Gu	004	Cowbell 4
039	Doumdoumba Rim	086	Madal Ta	133	Tang Gu Edge	005	Cowbell 5
040	BougarabouH Open	087	Madal Dun	134	Bajiaoogu Open	006	Cowbell 6
041	BougarabouH Slap	088	Khole	135	Bajiaoogu Mute	007	Cowbell 7
042	BougarabouH Bass	089	Khole Mute	136	Ohkawa	008	MegaCowbell
043	BougarabouM Open	090	Darabuka Dun	137	Tsuzumi S	009	MegaCowbell Mute
044	BougarabouM Slap	091	Darabuka Tek	138	Tsuzumi L	010	MegaCowbell Stmp
045	BougarabouM Bass	092	Darabuka TekMut	139	Shime Taiko	011	Agogo Hi
046	BougarabouL Open	093	Darabuka Snap	140	Hira Taiko	012	Agogo Lo
047	BougarabouL Slap	094	Darabuka SnapMut	141	Hira Taiko Rim	013	Apiyua
048	BougarabouL Bass	095	Darabuka Press	142	Nagado Taiko	014	Apiyua Mute
049	Talking Drum	096	Doira Dun	143	Nagado Taiko Rim	015	Apiyua Slide
050	Talking Drum Hi	097	Doira Tik	144	Concert BD	016	Grello
051	Pandeiro Thumb	098	Bendir Open	145	Concert BD Mute	017	African Bracelet
052	Pandeiro ThumbMt	099	Bendir Mute	146	20"March BD	018	African Jingle
053	Pandeiro Slap	100	Bendir Scrp	147	20"March BD Rim	019	Ankle Bells
054	Pandeiro Heel	101	Bendir Harm	148	24"March BD	020	MoroccanCasta Op
055	Pandeiro Toe	102	Riq Open	149	24"March BD Rim	021	MoroccanCasta Cl
056	Tamborim Open	103	Riq Mute	150	Cajon 1 Open	022	Chimta 1
057	Tamborim Mute	104	Riq Jingle	151	Cajon 1 Close	023	Chimta 2
058	Repinique Stick	105	Dawul Beater	152	Cajon 1 Slap	024	6"CrossMetal
059	Repinique Hand	106	Dawul Stick	153	Cajon 1 Bass	025	10"CrossMetal
						026	14"CrossMetal

OCTAPAD SPD-30 Instrument List

No.	Name
027	Metal Crasher
028	FlexMetal
029	FlexMetal BendUp
030	Sleigh Bells
031	Vibra Metal
032	Pin Chime
033	Tree Chime
034	Bell Tree
035	Triangle 1
036	Triangle 1 Mute
037	Triangle 2
038	Triangle 2 Mute
039	Crotale
040	Zil Open
041	Zil Close
042	Bali Cymbal
043	Bali Cymbal Mute
044	Bali Bells
045	Rama Cymbal
046	Finger Cymbal
047	Chenchen
048	Chenchen Mute
049	Chinese Cym Open
050	Chinese Cym Cls
051	Chinese Bell
052	Hu Yin Luo
053	Nao Bo
054	Xiao Bo
055	Thai Gong
056	Bend Gong
057	Tam Tam
058	Gong
059	Gengari
060	Gengari Mute
061	Atarigane
062	Church Bell
063	Waterphone Bow
064	Waterphone Shot
PC3: Miscellaneous percussion	
001	Claves 1
002	Claves 2
003	Hyoshigi
004	Kalaau S
005	Kalaau L
006	Knocker
007	Clicket
008	Block Hi

No.	Name
009	Block Lo
010	Block S
011	Wood Block Hi
012	Wood Block Lo
013	Temple Block Hi
014	Temple Block Lo
015	Korean Block
016	Log Drum Hi
017	Log Drum Lo
018	Ili-ili
019	Castanet
020	Clapsticks
021	Shaker 1
022	Shaker 2
023	String Bean
024	Ganza 1
025	Ganza 2
026	Ganza 3
027	Maracas 1
028	Maracas 2
029	Caxixi 1
030	Caxixi 2
031	Cabasa
032	Afuche
033	Shekere Shake
034	Shekere Tap
035	Shekere Net
036	Shekere Bottom
037	Shekere Roll
038	Nuts Rattle
039	Nuts Rattle Roll
040	Nuts Rattle 2
041	Ankle Beads
042	Chafchas
043	Guiro 1 Scrape
044	Guiro 1 Shot
045	Guiro 2 Scrape
046	Guiro 2 Shot
047	Rakatak
048	Ratchet
049	Ratchet Notch
050	Vibra-slap
051	Quijada
052	Devil Chaser
053	Rain Stick
054	Cuica
055	Cuica Mute

No.	Name
056	Berimbau Open
057	Berimbau Press
058	Berimbau Gourd
059	Music Bow
060	Gopijiantra
061	Whistle
062	Slide Whistle Up
063	Slide Whistle Dn
064	Jaws Harp
065	Jaws Harp Wow
066	Duck Call
067	Quad Horns
068	Didgeridoo
069	55 Claves
070	78 Cowbell
071	78 Metal Beat
072	78 Guiro
073	78 Tambourine
074	78 Maracas
075	78 Bongo
076	78 Claves
077	707 Cowbell
078	727 Agogo Bells
079	808 Conga
080	808 Claves
081	808 Maracas
082	808 Cowbell
PC4: Melodic percussion	
001	Hand Pan F0
002	Hand Pan C1
003	Hand Pan F1
004	Hand Pan A1
005	Hand Pan B1
006	Hand Pan C2
007	Hand Pan D2
008	Hand Pan F2
009	Tone Plate G0
010	Tone Plate C1
011	Tone Plate F1
012	Tone Plate A1
013	Tone Plate C2
014	Lithophone G0
015	Lithophone C1
016	Lithophone G1
017	Lithophone C2
018	Lithophone F2
019	Khongwong F0

No.	Name
020	Khongwong B0
021	Khongwong E1
022	Khongwong B1
023	Khongwong E2
024	Slit Drum F0
025	Slit Drum A0
026	Slit Drum D1
027	Slit Drum F1
028	Slit Drum G1
029	Balaphone C1
030	Balaphone G1
031	Balaphone E2
032	Balaphone B2
033	Balaphone GlissU
034	Balaphone GlissD
035	Gyilli A0
036	Gyilli D1
037	Gyilli G1
038	Gyilli C2
039	Gyilli G2
040	Gyilli GlissUp
041	Gyilli GlissDn
042	Angklung C
043	Kalimba C
044	Saron C
045	Bonang C
046	Gender C
047	Glockenspiel C
048	Marimba C
049	Xylophone C
050	Vibraphone C
051	Tublar Bells C
052	Tublar Bells G
053	Hand Bell C
054	Steel Drum C
055	Timpani G0
056	Timpani C1
057	Santoor C0
058	Santoor C1
059	HammerDulcimerC0
060	HammerDulcimerC1
061	Yang Qin C
062	Sitar C
063	Sitar Gliss
064	Tambura C
065	Tambura Drone

OCTAPAD SPD-30 Instrument List

No.	Name
MEL:	
Pitched instrument	
001	Suspense
002	Vector
003	Eerie
004	E-Drone
005	Purple Faze
006	Analog Syn 1
007	Analog Syn 2
008	Spooky
009	Buzzy
010	Synth Chord 1
011	Synth Chord 2
012	Choir 1
013	Choir 2
014	Orch Strings
015	OB Strings
016	Fantasia
017	Atmosphere
018	Feedback Wave
019	Plutone
020	Electra Bell
021	Pizz Box
022	Alien Pluck
023	Brass
024	Brass Fall
025	Ac Piano C0
026	Ac Piano C1
027	Ac Piano C2
028	Poly Bass
029	Saw Bass
030	TB303 Bass
031	SH101 Bass
032	Funky Bass
033	Acoustic Bass
034	Finger Bass
035	Sine
036	Super Saw
037	OB Saw
038	M Saw
039	Impact Sine
040	Impact Sine H
041	Impact Saw
042	Impact Saw H
043	Impact Square
044	Impact Square H
045	Impact Tri
046	Impact Tri H

No.	Name
047	Impact Juno
048	Impact Juno H
049	Techno Chord
050	Techno Scene
051	Techno Hit
052	Techno Beef
053	Techno Break
054	Philadelphia Hit
055	Percussion Hit 1
056	Percussion Hit 2
057	Orchestra Hit
058	Orch Hit Major
059	Orch Hit Dim
SFX:	
Sound effects	
001	Clap 1
002	Clap 2
003	Clap 3
004	Clap 4
005	Hip Clap
006	Gate Clap
007	Live Clap
008	101 Clap
009	808 Clap
010	909 Clap
011	Flamenco Clap
012	Finger Snaps
013	VOX Hooh
014	VOX Woow
015	VOX Whistle
016	VOC Gotit
017	VOC Count 1
018	VOC Count 2
019	VOC Count 3
020	VOC Count 4
021	VOC Count 5
022	VOC Count 6
023	VOC Count 7
024	VOC Count 8
025	Drum Sticks
026	Fight Gong
027	GrandfatherClock
028	Scratch
029	Scratch Kick
030	Tape Stop
031	Club FX
032	High Q
033	Pulse

No.	Name
034	Bz
035	Squelch
036	Emergency
037	Whistle Fx
038	Zip
039	Sweep
040	Chromatone
041	Space Beep
042	Stomped Box
043	Gate Crash
044	Metallic Flick
045	Gated Cricket
046	Super Shot
047	Junk
048	Cosmo Bell
049	Noise 1
050	Noise 2
051	Noise 3
052	Noise 4
053	PCM Press
054	Abstract Noise
055	Verby Crash
056	Presage
057	Digi Cup
058	Ejector
059	Echoic Shot
060	White Pulse
061	Super Low
OFF:	
Off	
001	Off

List of Inst groups

KIK	Kick (bass drum)
SNR	Snare drum
TOM	Tom-tom
HH	Hi-hat cymbal
RD	Ride cymbal
CYM	Miscellaneous cymbal
PC1	Percussion with heads
PC2	Metallic percussion
PC3	Miscellaneous percussion
PC4	Melodic percussion
MEL	Pitched instrument
SFX	Sound effects
OFF	Off

Copyright

When you purchase the SPD-30 from an authorized Roland dealer, the included sounds are licensed, not sold, to you by Roland Corporation, for commercial use in music production, public performance, broadcast, etc.

You may use any of the included sounds in a commercial or noncommercial recording without paying any additional license fees. However, you must strictly adhere to the following crediting guidelines on any music recording that utilize material from SPD-30.

Reproduction or duplication of any of the sound contained in the SPD-30, either as they exist on this sound module or by any means of reformatting, mixing, filtering, re-synthesizing, processing or otherwise editing for use in another product or for re-sale, is strictly prohibited without the express written consent of Roland Corporation. All unauthorized giving, trading, lending, renting, reissue, re-distribution or re-sale of the sounds included in the SPD-30 are expressly prohibited.

In Plain English: Be creative in your application of the SPD-30 sounds, and keep this sounds for your use only. DO NOT COPY IT.