

# TR-8 Update

## Contents of Ver. 1.12

### Switching the pattern sequencer's operating mode

Now you can change the operating mode of the pattern sequencer.

- \* Until Ver. 1.11, the sequencer operated with timing that models the TR-808.

1. While holding down the [PTN SELECT] button, turn on the power.
2. Press pad [7] to switch the operating mode.

ON (lit)	The pattern sequencer operates with precise timing.
OFF (unlit)	The pattern sequencer operates with timing that models the TR-808. (Default)

### Fixed a problem with TR-REC

We fixed the problem in which it became impossible to set LAST STEP to "1."

## Contents of Ver. 1.11

### Adding an accent to an instrument's performance

- When using INST-PLAY (realtime performance) or INST-REC (realtime recording), you can hold down the ACCENT [STEP] button and press a pad to add an accent to the specified step. To adjust the volume of the accent, use the ACCENT [LEVEL] knob in the same way as for TR-REC (step recording).
- INST-REC (realtime recording) now lets you record an accent at the step location that you play.

### Color indication of the instrument's sound (tone)

When selecting a tone, the color that is shown when you press a pad now distinguishes the tone.

TR-808 type	Pink
TR-909 type	Yellow

### Fixed a problem with ASSIGNABLE OUT

We have fixed a problem that had caused the effect sound to be sent to MIX OUT when an instrument with reverb or delay applied was assigned to ASSIGNABLE OUT.

- \* Properly speaking, an instrument assigned to ASSIGNABLE OUT should not be output from MIX OUT.

## Contents of Ver. 1.10

### Instrument gain setting

1. Press the [KIT] button.
2. Turn the [TEMPO] knob while holding down each instrument button from [BD] to [RC].  
Its range is from 0 to 200 (-24 dB to +24 dB).  
This parameter is stored within each kit.

### Scatter [ON] button mode

1. While holding down the [PTN SELECT] button, turn on the power.
2. Press [STEP5].

ON	Momentary
OFF	Latch (default)

### Scatter 1 cycle on

Press [ON] while holding down the [DEPTH] button.  
Scatter is enabled in current cycle only.

### Improved roll function

To play rolls, you can either press the instrument play buttons ([STEP1]–[STEP11]) first and then the roll variation ([STEP12]–[STEP15]) buttons, or vice versa.

## Data backup/restore

### ● Backup

1. Hold down [STEP2] and switch on the power.
2. Connect your computer to the TR-8's USB port via USB cable.
3. Open the "TR-8" drive folder on your computer.
4. Copy the TR-8 kit/pattern files in the "BACKUP" folder to your computer.

KIT 1-16	TR8_KIT1.PRM-TR8_KIT16.PRM
PATTERN 1-16	TR8_PTN1.PRM-TR8_PTN16.PRM

5. After copying is completed, disconnect the USB cable.

#### Windows 8/7

Right-click on the "TR-8" icon in "My Computer" and execute "Eject."

#### Mac OS

Drag the "TR-8" icon to the Trash icon in the Dock.

6. Turn the TR-8 power off.

### ● Restore

1. Hold down [STEP2] and switch on the power.
2. Connect your computer to the TR-8 USB port via USB cable.
3. Open the "TR-8" drive folder on your computer.
4. Copy the TR-8 kit/pattern files into the "RESTORE" folder.
5. After copying is completed, disconnect the USB cable.

#### Windows 8/7

Right-click on the "TR-8" icon in "My Computer" and execute "Eject."

#### Mac OS

Drag the "TR-8" icon to the Trash icon in the Dock.

6. Turn the TR-8 power off.

## Lock pattern data

Turn the [TEMPO] knob while holding down the [PTN SELECT] button to lock or unlock the current pattern.

When pattern is locked any editing is erased in the case of turning off the power or choosing another pattern.

## Edit Pattern A/B while playing the sequencer

Press the [A] or the [B] button while holding down the [TR-REC] button.

## Sync reset

Press the [START/STOP] button while holding down the [TAP] button. When you play a pattern, it returns to the beginning immediately.

## MIDI Local On/Off and MIDI Controller mode

1. Stop the sequencer.
2. Turn the [SCATTER] knob while holding down the [LAST STEP] button.

LOCAL ON	It produces sound through any operation including external MIDI message.
LOCAL OFF	It produces sound only through external MIDI message.
MIDI CONTROLLER	It doesn't produce sound through any operation, only outputs MIDI message.

## MIDI velocity is variable via accent setting

## Select kit number via program change messages

## MIDI implementation of scatter via control change

CC#70	SCATTER SW
CC#68	SCATTER TYPE
CC#69	SCATTER DEPTH

## MIDI implementation of effect via note messages

C0	ACCENT PATTERN ALL ON/OFF
D0	REVERB PATTERN ALL ON/OFF
E0	DELAY PATTERN ALL ON/OFF
F0	EXT. IN PATTERN ALL ON/OFF
G0	ACCENT PATTERN ALL MUTE
A0	REVERB PATTERN ALL MUTE
B0	DELAY PATTERN ALL MUTE
C1	EXT. IN PATTERN ALL MUTE

## Real time recording via external MIDI messages

### MIDI Off

No MIDI messages are transmitted out when the MIDI channel is set to OFF.

## Option to receive or ignore MIDI play/stop messages

1. While holding down the [PTN SELECT] button, turn on the power.
2. Press [STEP6].

ON	Only MIDI clock is received
OFF	MIDI clock, play, and stop messages are received (default)