

# Roland® DH-01 Compatible CD Drive List

| Manufacturer   | Model  |
|----------------|--|
| Freecom        | FX-50<br>FS-50   |
| lomega         | CD-RW 52X<br>CD-RW 52X DVD-ROM 16X<br>Super DVD Writer 16x<br>d2 DVD±RW with LightScribe |
| LaCie          | DVD±RW Drive Design by F.A. Porsche 16x<br>Slim DVD±RW Design by F.A. Porsche 8x         |
| LG Electronics | GSA-2166D  |
| Lite On        | EZ-DUB SHW-1635SU-03C<br>SOSW-8335X-03C  |
| Sony           | DRX-820UL  |
| Buffalo        | DVSM-XL516U2<br>CRW-52U2   |
| I/O Magic      | External USB 2.0 Slim DVD ReWritable Drive<br>IDVD8PE                                    |
| I-O Data       | DVR-UH16D<br>DVRP-UM8D   |
| Logitech       | LDR-PMA8U2   |
| Panasonic      | LF-M860JD  |
| Memorex        | DVD Double-Layer Recorder 16x16 Dual Format External<br>CD Recorder External Ultra Speed |

## Notice:

As of January 18, 2007, the CD drives listed above have been confirmed to operate normally with Roland Piano HP-207/HP-203/FP-7/RG-3.

\* Your particular drive may be unusable due to differences in individual product specifications, even with the same model drive, as well as differences in usage environments, media, and other factors. No guarantee is made for complete operability with the above models.

\* For information on obtaining any of these drives, consult the manufacturer for the respective device. Some drives may not be available in certain countries.

\* Relative Roland products are not compatible with any type of DVD media. You can use only the capability of reading CD media when using DVD/CD drives on the above list.

\* Not compatible with "USB bus power." Use the AC adaptor included with the drive or other compatible adaptor to power the drive.