# Drum Tutorial Software for HD-1

Roland's HD-1 V-Drum Lite is a big hit with beginners around the world. To enhance the HD-1 experience and help drummers learn the fundamentals, Roland has created DT-HD1, a fun, educational interactive software application. Connect your HD-1 to a PC via USB, launch the software, and play along and learn.

- ● 34 preset patterns with SMF compatibility
- ● Notation screen with bouncing ball and timing check with right and left hand instruction
- ● Game screen with falling blocks and score points

■ Notation Screen

- ● Metronome, A-B repeat, drum mute, drum and pad solo
- ● UM-1G USB-MIDI interface and audio cable included to connect the HD-1 to a computer
- ● Windows compatible (Vista/XP)

■ Game Screen

SS-PC1   Support Stand for PC

Position your laptop next to the HD-1 with this sturdy, custom-built stand. It's an ideal accessory when using DT-HD1 software with the HD-1.

*Computer not included

DT-HD1 Specifications

■ **Screens** Drum Notation Screen, Game Screen ■ **Preset Pattern** Basic (only drum pattern): 8, Primary: 10, Advanced: 16 ■ **Tempo** Quarter note = 20 to 250 ■ **Notes that can be shown in the Notation Area** Values: longer than 8th note triplets, Velocity: 20 or greater, Note number: corresponds to the pads of the HD-1, MIDI channel: 10 ■ **Playable Song Files** Format: Standard MIDI Files (Format 0/1), Number of Measures: 999 or less, Number of Events: 99,999 or less, Resolution: 24 ticks per quarter note or more ■ **Accessories** UM-1G USB-MIDI Interface, HD-1 Drum Tutor CD-ROM, Audio Cable, Cable Tie, Install Guide ■ **System Requirements** Operating System: Microsoft® Windows® XP SP2, Microsoft® Windows Vista® * This does not work with the 64-bit Edition of Windows®, CPU/Clock: Intel® Core™, Pentium® processor 1.2 GHz or higher (2.0 GHz or higher is recommended), RAM: 512 MB or more, Hard Disk: 25 MB or more, Display/Colors: 1024 x 768 or higher/65,536 colors (16 Bit High Color) or more, Others: CD-ROM Drive, USB Port

* The specifications are subject to change without notice.