

Designed for use at home, the CUBE Lite contains a 2.1 ch speaker system that gives you great-sounding audio playback as well as the quality you expect from a guitar amp.

- With specially designed stereo speakers and subwoofer, this unit delivers powerful lows while faithfully reproducing the finest nuances of your guitar sound.
- The i-CUBE LINK jack allows the CUBE Lite to serve as an audio interface for your iPad/iPhone. This makes it possible for you to take advantage of your recording/playback and effects processing apps.

Before using this unit, carefully read the sections entitled "USING THE UNIT SAFELY" and "IMPORTANT NOTES" (separate sheet). These sections provide important information concerning the proper operation of the unit. Additionally, in order to feel assured that you have gained a good grasp of every feature of your new unit, read Owner's manual in its entirety. This manual should be saved and kept on hand as a convenient reference.

Copyright © 2012 ROLAND CORPORATION

All rights reserved.

No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

Top Panel (Adjusting the Guitar Sound)

[DRIVE] knob
Adjusts the amount of distortion for the amp.

Amp type switch/Indicator
The amp type will change each time you press the switch.

Indicator	Type	Explanation
Green	JC CLEAN	A modeled Roland JC-120 amp
Orange	CRUNCH	An original crunch sound amp
Red	EXTREME	An original high-gain amp

[CHORUS/REVERB] knob
Change the position of this knob to switch between chorus and reverb. The position of the knob determines the depth of the effect.

[VOLUME] knob
Adjusts the volume of the guitar sound.

[BASS] knob
Adjusts the tone of lower-range sound.

[TREBLE] knob
Adjusts the tone of upper-range sound.

Rear Panel (Connecting Your Equipment)

[POWER] switch
Turns the power on and off.

PHONES jack
Connect headphones equipped with a stereo mini-plug.

INPUT jack
Connect your guitar here.

DC IN jack
Connect the included AC adaptor here.
* Use only the included AC adaptor. The use of any other AC adaptor may cause malfunction.

i-CUBE LINK/STEREO AUX IN jack (dual function)

i-CUBE LINK
If you use the included mini cable (4-pole) to connect your iPad/iPhone, you'll be able to use the i-CUBE LINK function.

STEREO AUX IN
Use the included mini cable (4-pole) or a commercially available stereo-mini cable to connect your digital audio player or iPad/iPhone here.

[VOLUME] knob
Adjusts the volume of the input from the connected device.

NOTE
To prevent malfunction and equipment failure, always turn down the volume, and turn off all the units before making any connections.

Turning the Power On and Off

• Once everything is properly connected, be sure to follow the procedure below to turn on their power. If you turn on equipment in the wrong order, you risk causing malfunction or equipment failure.


When turning the power on: Turn on the CUBE Lite last.

When turning the power off: Turn off the CUBE Lite first.

• This unit is equipped with a protection circuit. A brief interval (a few seconds) after turning the unit on is required before it will operate normally.

Using i-CUBE LINK

"i-CUBE LINK" is a function that allows the CUBE Lite to be used simultaneously for conventional AUX IN and as an audio interface for your iPad/iPhone when the iPad/iPhone is connected via the included mini cable (4-pole).



By making use of this function, you can do things such as the following:

- Use an iPad/iPhone app to record music played on your guitar, then play it back through the CUBE Lite.
- Use an iPad/iPhone app to apply effects to your guitar's sound, then have the CUBE Lite play the sound.

* If you want to hear only the sound that's being input from the iPad/iPhone, turn down the [VOLUME] knob on the top panel.

You can choose one of the following two types of guitar sound to be sent to the iPad/iPhone.

Line Mode (default setting)	The same guitar sound as heard from the CUBE Lite's speakers will be sent.
Direct Mode	The guitar sound being input to the INPUT jack will be sent without modification.

To select Direct Mode

1. While holding down the Type switch, press the [POWER] switch to turn on the CUBE Lite's power.

The amp type indicator will blink, and will then remain lit.



To return to Line mode, turn the CUBE Lite's power off, then on again.

For details on i-CUBE LINK and on iPhone/iPad apps that can use i-CUBE LINK, refer to Roland website.

<http://www.roland.com/>

Specifications

Roland CUBE Lite: Guitar Amplifier

Rated Power Output	10 W (Stereo Speakers 3 W x 2 + Subwoofer 4 W)
Nominal Input Level (1 kHz)	INPUT: -10 dBu i-CUBE LINK/STEREO AUX IN: -10 dBu
Speakers	7.5 cm (3 inches) x 3
Amp Types	JC CLEAN, CRUNCH, EXTREME
Controls	POWER switch Amp Type switch DRIVE knob VOLUME knob BASS knob TREBLE knob CHORUS/REVERB knob <i-CUBE LINK/STEREO AUX IN> VOLUME knob
Indicator	Amp Type

Connectors	INPUT jack (1/4-inch phone type) i-CUBE LINK/STEREO AUX IN jack (4-pole miniature phone type) PHONES jack (Stereo miniature phone type) DC IN jack
Power Supply	AC Adaptor (DC 5.7 V)
Current Draw	1000 mA
Dimensions	250 (W) x 147 (D) x 135 (H) mm 9-7/8 (W) x 5-13/16 (D) x 5-3/8 (H) inches
Weight	1.7 kg/3 lbs 12 oz (excluding AC Adaptor)
Accessories	Owner's Manual AC Adaptor Mini Cable (4 poles)

* 0 dBu = 0.775 Vrms

* In the interest of product improvement, the specifications and/or appearance of this unit are subject to change without prior notice.

Guide pin

You can connect a commercially available wire here to secure the CUBE Lite.

* To prevent damage, do not apply excessive force to the guide pin.

